



ZLWL IR5000 Series 4G Industrial Router Product Instruction Manual

CONTENTS

CONTENTS	1
1. Product Description	8
2. Device login and system status check	9
2.1 Hardware interface	9
2.2 Installation of SIM Card and Antenna	11
2.3 Indicator status	11
2.4 Web page login	14
3. System Status	16
3.1 Overview	16
3.1.1 Status bar	16
3.1.2 Mobile WAN network and wired WAN status view	17
3.1.3 Memory usage and DHCP connection list	17
3.1.4 WiFi Access Point information	18
3.1.5 Load Balancing (optional)	19
3.2 Routing Table	19
3.3 System Log	20
3.4 Kernel Log	20
3.5 Real-time information	21
3.6 Load balancing	21
4. Basic Network	24
4.1 Switch	24
4.2 Hostnames	24
4.3 Static Routing	25
4.4 Wired Network	26
4.4.1 WAN Interface	26
4.4.1.1 DHCP Client	27

4.4.1.2 Static(wan) address	27
4.4.1.3 PPPoE dial-up	28
4.4.2 LAN Interface	29
4.4.3 MGT Interface	31
4.5 mobile network	31
4.5.1 DHCP Dial (single modul single SIM)	32
4.5.1.1 Auto network (default)	33
4.5.1.2 Lock the network (4G/3G/2G)	36
4.5.2 PPP Dial	37
4.5.2.1 Automatic network	38
4.5.2.1 Lock the network (4G/3G/2G)	38
4.6 Wireless Network	38
4.6.1 AP mode	39
4.6.1.1 Device Configuration	39
4.6.1.2 Interface Configuration	40
4.6.2 Client Mode	43
4.6.2.1 Client DHCP (default)	44
4.6.2.1 Client static address	46
4.7 Static address	48
5. Advanced Network	48
5.1 QoS	48
5.2 DMZ	49
5.3 Firewall	49
5.3.1 Basic Settings	49
5.3.2 Communication rules	50
5.3.3 Domain name filtering	52
5.3.4 Keyword filtering	52
5.4 Portal authentication (optional)	52
5.4.1 General arrangement	53

5.4.1.1 Local Upload	53
5.4.1.2 Download file from URL server address	53
5.4.2 counter	54
5.4.3 Filter	55
5.4.4 other	56
5.5 Repeater	56
5.6 Port forwarding	56
5.7 Static NAT	57
5.8 Smarklink	58
5.8.1 General	59
5.8.1.1 Mode configuration	59
5.8.1.2 Connection configuration	60
5.8.1.3 Serial port configuration	61
5.8.2 advanced	62
5.8.3 Operating mode	63
5.8.4 Custom protocol	63
5.8.5 Configuration example	65
5.8.5.1 TCP server	65
5.8.5.2 TCP Client	68
5.8.5.3 UDP Server	71
5.8.5.4 UDP Client	71
5.8.5.5 Real serial port mode	71
5.8.5.6 MQTT Client	72
5.8.5.7 Modbus RTU to TCP master-slave communication	74
5.8.5.8 Modbus TCP master-slave communication	74
5.9 M2M Cloud platform	74
5.10 Load Balancing (optional)	75
5.10.1 Global	76
5.10.2 Interface	77

5.10.3 Member	79
5.10.4 Strategy	79
5.10.4.1 wan_only	80
5.10.4.2 wwan_only	80
5.10.4.3 3gwan_only	80
5.10.4.4 balanced	81
5.10.4.5 balanced_wan	81
5.10.4.6 wan_primary	81
5.10.4.7 wwan_primary	81
5.10.4.8 3gwan_primary	82
5.10.4.9 wan_wwan_4G	82
5.10.5 Rule	82
5.11 Intranet penetration (optional)	83
5.12 Network Monitoring	83
6. Virtual Private Network	85
6.1 GRE Client	85
6.2 PPTP Client	88
6.3 L2TP Client	91
6.4 IPSec Client	95
6.4.1 IPSec security strategy	95
6.4.1.1 Basic Settings	95
6.4.1.1 Security proposal	96
6.4.2 IPSec Security Alliance	99
6.5 EOIP Client	99
6.6 N2N VPN Client	100
6.7 OPEN VPN	101
7. System Management	104
7.1 System	105
7.1.1 System property	105

7.1.1.1 General Settings	105
7.1.1.2 Modification of WAN mode	105
7.1.2 Time synchronization	107
7.2 Administration	108
7.3 Backup/flush Firmware	108
7.3.1 Generate Archive	109
7.3.2 Perform Reset	109
7.3.3 Upload Archive	110
7.3.4 Flash Image	110
7.4 System diagnostics	111
7.5 Device Reboot	112
7.5.1 Reboot now	112
7.5.2 Reboot timer	112
8.Exit.....	111
9. Overview of Router Open Ports.....	111
Appendix: Network Abbreviations	115



Copyright © 2013 ~ 2022, Shenzhen ChiLink IoT Technology Co., Ltd. All Rights Reserved.

Without the written permission of the Company, no unit or individual shall excerpt or copy part or all of the contents of this document, and shall not be disseminated in any form.

Trademark Statement



And other trademarks are trademarks of Shenzhen ChiLink IoT Technology Co., Ltd.

ZLWL is our Chinese name: **Zhi Lian Wu Lian**

ChiLink is from China, Link the world.

All other trademarks or registered trademarks referred to in this document are the property of their respective owners.

Pay attention to

The products, services or features you purchase shall be subject to the commercial contracts and terms of Shenzhen ChiLink IoT Technology Co., Ltd., and all or part of the products, services or features described in this document may not be within the scope of your purchase or use. Except as otherwise agreed herein, Shenzhen ChiLink IoT Technology Co., Ltd. makes no representation or warranty, express or implied, regarding the contents of this document.

The content of this document may be updated from time to time due to product version upgrade or other reasons. Unless otherwise agreed, this document is intended as a guide to use only, and all statements, information and recommendations contained in this document do not constitute any warranty, express or implied.



Shenzhen ChiLink IoT Technology Co., Ltd.

Email:sales@chilinkiot.com

Http://www.szchilink.com

Http://www.chilinkiot.com

ChiLink is from China, Link the world.

Shenzhen Chilink IOT Technology CO., LTD.

Add:#518,#512,Block A,Famous Industrial Product Display

&Purchasing Center,Baoyuan Road,Baoan District,Shenzhen,China

Document Revision Records

Date	Version	Description	Author
2015-5-15	V1.0	Initial Release	MC
2017-6-6	V1.1	Supplement/Amendment	MC/DHL
2019-10-8	V1.2	Update	MC/DHL
2021-9-18	V2.0	Update	MC/DHL



1. Product Description

Our router series adopts industrial design, adopts high-performance 32-bit embedded MIPS architecture dedicated network processor, embedded with industrial-grade, high-performance, multi-band mobile 3G/4G communication processing module. Support WCDMA, HSPA+, TD/FDD-LTE, EVDO (CDMA 2000), TD-SWCDMA, GSM and other high-speed mobile broadband network, to provide customers with convenient and fast Internet access or private network transmission, optional embedded Wi-Fi module or multi-LAN port. Provide customers with wired fixed network or wireless WLAN sharing high-speed broadband connection; At the same time, we provide customized advanced VPN (OpenVPN, IPSec) functions to build safe tunnels, which are widely used in finance, electric power, environmental protection, oil, transportation, security and other industries.

The Router series provides users with a Web-based configuration interface, making it very easy to configure and manage the Router. At the same time, the M2M terminal product management platform provides users with remote management of all Router terminals. Through the M2M platform, users can monitor the status of all terminals successfully connected to the platform, and provide remote control, parameter configuration and remote upgrade services.

This instruction manual introduces to the user how to install and configure the industrial grade Router, and guides the user to get started and use our products quickly after correctly installing the hardware and configuring the basic parameters.


2. Device login and system status check

This chapter mainly introduces and instructs the customer how to judge the current network connection of the device through the state of each indicator light outside the device, and at the same time instructs the user how to connect to the routing device through the computer or other wireless terminals to set and view some parameters. The detailed description is as follows:

2.1 Hardware interface



Front panel schematic diagram



Side panel schematic diagram

- 1) 2.4G WiFi: 2.4GHz frequency band WiFi SMA interface;
- 2) 4G Interface: SMA interface for 4G network antenna, which automatically downwardly compatible with 3G/2G network signals;

3) SIM1/SIM2: Dual SIM card slots, requiring installation of standard large SIM cards;
<SIM Card Installation Diagram>: When installing, place the SIM card with its chip circuit facing upward, aligning with the small triangle direction at the bottom of the card holder, then push the entire card slot upward to complete installation. (Note: Hot swapping of SIM cards is not supported. It is recommended to power off the device first before removing or inserting a SIM card to avoid damaging the SIM card);

4) SIM Card Ejection Button: Press here with a SIM card ejector pin or other sharp object to eject the SIM card holder;

5) LAN1-LAN4 Ports: Network ports for connecting LAN computers or other terminal devices;

6) WAN Port: Defaults to WAN port status; can be changed to LAN port use after modification;

7) RST: Reset button. When the device is powered on, press and hold this button for about 10 seconds, then release it. All lights will flash on and off once to indicate the completion of reset;

8) Serial Port 232/485: Select either one. The description of each terminal interface is as follows:
3.3V: Serial port power supply, generally no need to connect;
GND: Signal ground;
TX/B: 232/485 transmit signal;
RX/A: 232/485 receive signal;

9) POWER: Device power DC connector, supporting a wide DC voltage range of 7.5V~32V. The default power adapter is DC12V/1A;

2.2 Installation of SIM Card and Antenna

SIM Card Installation:

The device only supports the installation of standard Mini SIM cards. If a Nano/Micro SIM card is used, please install a card adapter first before use.


When installing the SIM card as follows, press the ejection hole indicated by the blue arrow in the figure with another object, and the card holder will pop out automatically. When placing the card, ensure the SIM chip circuit faces upward, align the notch of the card with that of the card holder, and finally gently push the card holder back into place.

Installation of WiFi/4G Network Antennas:

As described above, the antennas are divided into WiFi antennas (2.4GHz) and 4G network antennas (compatible with 3G/2G). When using the device for the first time, please first remove the small red caps from the interfaces. Then, install the antennas by screwing them clockwise one by one as shown in the diagram (the antennas support bending at different angles).

By default, rod-shaped antennas are provided, which are compatible with both WiFi and mobile networks. When in use, please ensure that all antennas are properly connected.

2.3Explanation of Network Indicator Lights



Note: The IR5000 4G router supports single-mode dual-SIM mode.

In single-mode dual-SIM mode, both SIM1 and SIM2 can be inserted and used (dual SIM cards with single standby). The device prioritizes checking and using the SIM1 network: when the network of SIM1 is normal, it will consistently use the SIM1 network. If the dial-up of SIM1 network fails or is abnormal, the device will start switching to check the SIM2 network; when the SIM2 network is normal, it will consistently use the SIM2 network. If the SIM2 network is also abnormal, the device will continuously switch between checking SIM1 and SIM2 networks until a successful network connection is established.

Serial Number	Dialing Status	SIM usage	NET indicator status	SIM status	network status
1	Dialing Failed	No SIM	The green light flashes slowly, and finally goes out	SIM not inserted	not connected
2		Invalid or damaged SIM		Unplugged SIM Or SIM abnormal	
3		SIM installation error			
4	Dialing	SIM is normal	Flashes Quickly	simready	connecting
5	When SIM1 dial-up is successful	1<=Signal value (weak)<=10	S1 stays on steadily / S2 stays off steadily / N light flashes slowly		
6		11<signal value (general)<=20	S1 stays on steadily / S2 stays off steadily / N light		



ZLWL Industrial 4G Router Manual


			flashes quickly	simready	connected
7		21<signal value (stronger)<=31	S1 stays on steadily / S2 stays off steadily / N light stays on steadily		
8		1<=Signal value (weak)<=10	S2 stays on steadily / S1 stays off steadily / N light flashes slowly		
9	When SIM2 dial-up is successful	11<signal value (general)<=20	S2 stays on steadily / S21stays off steadily / N light flashes quickly		
10		21<signal value (stronger)<=31	S2 stays on steadily / S1 stays off steadily / N light stays on steadily		

2.4 Web page login

The industrial router products of Chilink support users to view and set relevant product parameters with the login mode of Web terminal. The specific operations are as follows.

Step1: Hardware connection

Connect the router's LAN port to the computer. The computer's LAN card can set the automatic access address (or set the static IP address, but make sure it is on the same network as the router, otherwise you will not be able to log in to the router later. The default LAN address of the router is 192.168.1.1, and the netmask is 255.255.255.0) .




Device connection

Step 2: Check your computer's IP address

Open the computer's local connection and check whether the computer has obtained an IP address.

Step 3: Log on to the router Web using your browser

Open any browser, log in at the default address 192.168.1.1, enter the default user name/password admin/Admin@123(Factory pre-configuration can be customized according to user requirements.) (for the safety of the device, it is strongly recommended to change the default password when using the device, please refer to Section 7.2 "Management Rights" for details), and finally press Enter to enter the device Web page. As follows:



3. System Status


This chapter mainly instructs the user how to view the current status information of the routing device through this function, and make a preliminary judgment of the status of the current network access.

3.1 Overview

After logging in the router Web, click "System Status" -- "Overview". Here you can view some detailed information of the product, as follows:

3.1.1 Status bar

Here you can view the product system name, product model, product serial number, firmware version, hardware type (single module single card/dual module dual card), MAC address, WAN mode (wired mode/compatible mode /3G4G mode), load situation and other information.




The screenshot shows the 'Overview' tab selected in the left sidebar under 'System Status'. The main content area displays the 'Status' section with the 'System' tab selected. The table provides the following information:

System	Value	System	Value
Router Name	M2M	Product Name	ZR2740S
Firmware Version	Premium Wireless Router v2.2.201124	Product ID	11202ZR22103110004
Local Time	Wed May 12 16:02:41 2021	Hardware Class	Single Model Single Card
Uptime	0h 5m 30s	MAC Address	34:0a:68:25:b5:5e
Load Average	2.61, 1.75, 0.79	WAN Mode	3G/4G and Wired

3.1.2 Mobile WAN network and wired WAN status view

Here you can view the mobile network status details of the device, such as: SIM card insertion status and 3G/4G dialing details, 4G module identification, base station network received signal strength (RSSI) and the current network connection duration, etc.



4G WAN Status

Interface	Mobile Network1
Address	10.80.246.230
Gateway	10.80.246.231
DNS	211.136.17.107 / 211.136.20.203
Modem Type	LTE/WCDMA/TD-SCDMA/EVDO/CDMA/EDGE/GPRS/GSM
Modem ICCID	898604061918C0672484
Modem IMEI	863900051039125
Modem IMSI	460042615709484
Network Operator	China Mobile
Current Network Standard	LTE TDD
USIM Status	simready(SIM1)
RSSI	31 (-51 dBm / 100%)
ConnectStatus	connected 0h 5m 9s

Network

Wired WAN Status

Type: dhcpc
Address: 192.168.10.161
MAC Address: 34:0A:68:25:88:5E
Netmask: 255.255.255.0
Gateway: 192.168.10.1
DNS 1: 202.96.139.43
Expires: 23h 54m 11s
Connected: 0h 5m 49s

Active Connections

3.1.3 Memory usage and DHCP connection list

Here you can view the current memory usage of the device, including available memory, unused memory, buffers.

You can also view the list of devices connected to the DHCP server.



3.1.4 WiFi Access Point information

Here you can view the WiFi enabled status and working mode (AP/Client) of the device. At the same time, you can also check which wireless terminals are connected below, such as mobile phones, laptops, etc.

3.1.5 Load Balancing (optional)

Here you can view the load balancing (MWAN3) interface status of the device (3G/4G mobile WAN and wired WAN), such as online or offline.

3.2 Routing Table

Here you can view the current host address list information through the ARP list; All active IPv4 and IPv6 routing links can be viewed at the same time as follows.

Network	Target	IPv4-Gateway	Metric	Table
wan	0.0.0.0	192.168.10.1	10	1
3gwan1	10.80.246.0/24	-	20	1
lan	172.16.0.0/24	-	0	1
lan	192.168.1.0/24	-	0	1
wan	192.168.10.0/24	-	10	1
3gwan1	0.0.0.0	10.80.246.231	20	3
3gwan1	10.80.246.0/24	-	20	3
lan	172.16.0.0/24	-	0	3
lan	192.168.1.0/24	-	0	3
wan	192.168.10.0/24	-	10	3
3gwan1	0.0.0.0	192.168.10.1	10	main
3gwan1	10.80.246.0/24	10.80.246.231	20	main
lan	172.16.0.0/24	-	0	main
lan	192.168.1.0/24	-	0	main
wan	192.168.10.0/24	-	10	main

3.3 System Log

Here you can view the log details of the current function modules of the device.

When there is an abnormal operation of the device, we can locate the on-site problems of the customer according to the log.

3.4 Kernel Log

Here you can view the device background system driver interface startup information, when there are some device connection or startup abnormalities, you can use these logs to further locate customer field problems.

3.5 Real-time information

Here you can view the device load in real time (such as the load details in the 1st, 5th and 15th minutes), the upstream and downstream real-time traffic situation of different network interfaces, the signal and noise situation of WIFI and the link of other activities.

Time Interval	1 Minute Load	5 Minute Load	15 Minute Load	Average	Peak
4m	7.68	5.44	2.61	7.27	7.68
5m		5.25		5.25	5.44
15m		2.49		2.49	2.61

3.6 Load balancing

1) Interfaces


Here you can check the current online and offline status of each interface (WAN for wired WAN, WWAN for wifi client, 3gwan1 for 3/4G mobile network) of the system after the load balancing function is enabled (the system does not open load

balancing by default, if you need to use it, please place an order and comment).



2) Detail

Here is a detailed view of the current load-balancing IPv4 / IPv6 policy rule status).



```

Interface status:
interface wan is online and tracking is active
interface wwan is offline and tracking is down
interface 3gwan1 is online and tracking is active

Current ipv4 policies:
3gwan_only:
3gwan (100%)
3gwan_primary:
3gwan1 (100%)
balanced:
3gwan (50%)
wan (50%)
balanced_wan:
3gwan (33%)
wan (66%)
wan_only:
wan (100%)
wan_primary:
wan (100%)
wan_wwan_4g:
wan (100%)
wan_4g:
wan_4g (100%)
wan_unreliable:
wan_unreliable:
wwan_primary:
3gwan (100%)

Current ipv6 policies:
3gwan_only:
unreachable
3gwan_primary:
unreachable
balanced:
unreachable
balanced_wan:
unreachable
wan_only:
unreachable

```

3) Diagnosis

Here, the system WAN or 3GWN1 interface can be respectively tested for connectivity to confirm whether the current network is normal and available.



System Status Overview Routes System Log Kernel Log Realtime Graphs Load Balancing Basic Network Advanced Network VPN Configuration System Management Logout

Load Balancing-Diagnostics

Interface: 3gwan1 Task: Ping tracking IP EXECUTE

```
PING 114.114.114.114 (114.114.114.114): 56 data bytes
64 bytes from 114.114.114.114: seq=0 ttl=75 time=104.235 ms
64 bytes from 114.114.114.114: seq=1 ttl=68 time=103.637 ms
64 bytes from 114.114.114.114: seq=2 ttl=67 time=74.092 ms
64 bytes from 114.114.114.114: seq=3 ttl=67 time=72.734 ms
64 bytes from 114.114.114.114: seq=4 ttl=62 time=72.187 ms

--- 114.114.114.114 ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 72.187/85.377/104.235 ms
PING 208.67.220.222 (208.67.220.222): 56 data bytes
64 bytes from 208.67.220.222: seq=0 ttl=50 time=61.566 ms
64 bytes from 208.67.220.222: seq=1 ttl=50 time=71.575 ms
64 bytes from 208.67.220.222: seq=2 ttl=50 time=78.460 ms
64 bytes from 208.67.220.222: seq=3 ttl=50 time=82.144 ms
64 bytes from 208.67.220.222: seq=4 ttl=50 time=58.850 ms

--- 208.67.220.222 ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 58.850/70.519/82.144 ms
PING 208.67.222.220 (208.67.222.220): 56 data bytes
64 bytes from 208.67.222.220: seq=0 ttl=49 time=54.046 ms
64 bytes from 208.67.222.220: seq=1 ttl=49 time=53.475 ms
64 bytes from 208.67.222.220: seq=2 ttl=49 time=53.234 ms
64 bytes from 208.67.222.220: seq=3 ttl=49 time=72.223 ms
64 bytes from 208.67.222.220: seq=4 ttl=49 time=72.315 ms


--- 208.67.222.220 ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 53.234/61.050/72.315 ms
```

4. Basic Network

This chapter mainly introduces several different external network access scenarios supported by our router, including wired WAN network, WIFI client network, 4G mobile dial up network, etc. The following mainly introduces the use of these specific configuration methods.

4.1 Switch

This part can divide the device into VLAN to divide the system network into different network segments. The details are brief.




VLAN ID	CPU (eth0)	LAN 1	LAN 2	LAN 3	LAN 4
1	Port status: tagged	no link	100baseT full-duplex	no link	no link

4.2 Hostnames

Here, by clicking the "add" button, you can customize the host name of the device connected to the router based on their different IP address.


Example configuration: Customize a host named 'my_device' for the computer with IP address 192.168.1.152 connected to the router. You can see this host information in the System State Overview section.



The screenshot shows the 'Hostnames' configuration page. The left sidebar is the navigation menu. The main area shows a table for 'Host entries' with a single row: 'my_device' (Hostname) and '192.168.1.152 (PC-201911141944.lan)' (IP address). There are 'ADD', 'DELETE', 'SAVE & APPLY', and 'RESET' buttons at the bottom. The status bar at the top right says 'Connected: 0h 17m 44s'.

4.3 Static Routing

This section allows you to view all the current IPv4 / IPv6 dynamic routing tables of the system; You can also create a static routing table (mainly IPv4) by clicking the "Add" button to set up communication with the specified target network.




The screenshot shows the 'Static Routes' configuration page. The left sidebar is the navigation menu. The main area shows two tables: 'Static IPv4 Routes' and 'Static IPv6 Routes'. Both tables are currently empty, with a note 'This section contains no values yet'. There are 'ADD' buttons at the bottom of each table. The status bar at the top right says 'Connected: 0h 17m 44s'.

4.4 Wired Network

This chapter mainly introduces several different network configuration modes of wired WAN in routing system, including dynamic WAN address, static WAN address, and PPPOE broadband dial-up mode.


4.4.1 WAN Interface

Cable WAN network mode is to point to by a line bridge connecting mode connect a router's WAN port to another (superior) the router LAN port and make itself has the capability of network access (supervisor should pay attention to union of two router LAN network cannot be completely the same, otherwise result in network conflicts, you can change any of a router LAN address to avoid conflict).



4.4.1.1 DHCP Client

As shown in the figure below, the system defaults to the working mode of "DHCP client", that is, after accessing the superior router network, it will automatically obtain the IP address to access the Internet.



4.4.1.2 Static(wan) address

In addition to automatic WAN access, you can also set the static IP address (must be set to the same network segment as the router above, the mask must be the same, the gateway address and the DNS address also need to be set; For example, the parent router network is 192.168.10.0/24, and the gateway address is 192.168.10.1).

The configuration is as follows:

Select "Basic Network" -- "Wired Network" -- "WAN" -- "General Setup", select the protocol as "Static Address", then switch the protocol and set IP address, subnet mask, gateway address and DNS server, and save the application.

WAN

Interfaces - WAN

Common Configuration

General Setup

Status: Uptime: 0h 20m 23s
MAC: 34:0A:68:25:BB:5E
RX: 1.15 MB (8830 Pkts.)
TX: 85.5 KB (1306 Pkts.)
IPv4: 192.168.10.161/24

Protocol: Static address

Really switch protocol? **SWITCH PROTOCOL**

Protocol: Static address

IPv4 address: 192.168.10.168

IPv4 netmask: 255.255.255.0

IPv4 gateway: 192.168.10.1

IPv4 broadcast: 223.5.5.5

IPv6 assignment length: disabled

Type: static
Address: 192.168.10.168
MAC Address: 34:0A:68:25:BB:5E
Netmask: 255.255.255.0
Gateway: 192.168.10.1
DNS 1: 223.5.5.5
Connected: 0h 0m 32s

4.4.1.3 PPPoE dial-up

This method mainly refers to using a broadband account assigned by a carrier or other ISP network provider to access the Internet.

Configuration actions:

Select "Basic Network" -- "Wired Network" -- "WAN" -- "General Setup" and select the protocol as "PPPoE". After switching the protocol, fill in the corresponding PAP/CHAP user name and password, and save the application.

4.4.2 LAN Interface

The router gateway IP address is 192.168.1.1 by default. You can also set the DHCP server configuration here.

1) LAN address modification

The default router LAN gateway IP address is 192.168.1.1, netmask 255.255.255.0. You can use the image below to change the IP address and netmask and save the

application, and then use the new address to access the router configuration page.


2) DHCP server configuration

The router DHCP server is enabled by default. You can also set the starting address of the address pool, the maximum number of addresses, the expiration date of the address lease, and the use of specific DNS server addresses. Of course, you can turn it off if you need to.

4.4.3 MGT Interface

This interface is used as an alternate address (usually when the LAN port gateway address is forgotten or the current network address is used in conflict).

After connecting the computer to the router LAN port with a network cable, it is necessary to manually configure the IP with the same network segment as the MGT management address (the default is 172.16.0.1). Then enter 172.16.0.1 in the browser to log in to the router.



4.5 Mobile network

3G/4G wireless router is a kind of wireless communication equipment for the Internet of Things, which supports international standard FDD-LTE, TDD-LTE, WCDMA (HSPA+), CDMA2000 (EVDO), TD-Scdma GSM (GPRS/EDGE)/CDMA 2G/ The 3G/4G mobile broadband network standard provides users with convenient and fast high-speed network transmission functions.



Here we mainly introduce two different dialing methods of mobile network and the configuration and use of accessing APN and VPDN network. At present, our company's 5-mode and 7-mode full Netcom 3G/4G router equipment supports all operators' network standards. Actually, it depends on the type of router modem selected by the user and the local operator's network support.

4.5.1 DHCP Dial (Single-mode dual-SIM)

By default, the device uses DHCP dialing, which is also the preferred module dialing method supported by most module manufacturers. This method has fast dialing speed and strong compatibility. This way of dialing generally does not need to manually configure the SIM card APN information. When dialing, the device will automatically recognize the different APN information of the operator (note that some IoT cards or VPDN private network cards need to manually configure the APN information, user name and password, otherwise the dialing will fail).

Specific operation: select "Basic Network" --- "Mobile Network" --- "3GWAN1" --- "Basic Settings", select "Protocol".

The main dialing parameters are described as follows:

【Protocol】: Optional DHCP client / PPP mode dial-up;

【Hostname sent when requesting DHCP】: Default is M2M;

【Pre-configured APN before CM dial-up】: Enabled by default. Common APN information will be pre-configured before CM dial-up to be compatible with common APNs of various operators.

【SIM default APN】: Enabled by default. The system's pre-configured APN information will be used before SIM dial-up. If custom APN information is required, select "Disable", then fill in the custom SIM APN information, as well as the SIM PAP/CHAP username and password.

【PIN】: SIM card PIN code; the default setting is sufficient, and generally no additional configuration is needed;

【Network type】: Default is "Auto"; you can manually select "Auto 4G/3G/2G" mode;

【SIM frequency locking】: After selecting a specific network type, you can lock the corresponding supported frequency bands to ensure dial-up and network access on the specified frequency bands.

【SIM card mode】: You can lock the device's card reading mode to SIM1, SIM2, dual-card backup, or GNSS (no card reading, only GPS usage);

【SIM smart card】: Disabled by default. If Guangdong Yika or SDK-free cards need to be used, select the corresponding option for dial-up.

【SIM operator mode】: Default is "Auto"; you can manually lock the operator to China Mobile, China Unicom, or China Telecom.

【SIM IP protocol】: Default is IPv4, dialing only to IPv4 addresses. You can manually select IPv4/IPv6 or IPv6 to dial to IPv4 and IPv6 addresses, or only to IPv6 addresses.

【APN】: Network access point required by the operator's SIM card, generally required for IoT cards;

【PAP/CHAP username】: Username authentication required for dial-up, to be filled in according to specific circumstances;

【PAP/CHAP password】: Password authentication required for dial-up, to be filled in according to specific circumstances;

【Authentication type】: Including CHAP/PAP authentication;

【SIM card type】: Default is "Public network card"; you can manually select the card type as "Public network card" or "Private network card".

【SIM-C-IMSI】: Disabled by default; you can manually enable this function and configure C-IMSI.

【SIM card detection strategy】: You can manually select the SIM detection strategy as RSSI signal, Ping delay, or a hybrid strategy of both.

【RSSI signal】: Set the RSSI signal threshold; if the signal is lower than this value, the dial-up connection will be judged as interrupted.

【Ping delay】: Set the Ping address and Ping delay threshold; if the Ping detection delay exceeds the threshold, the dial-up connection will be judged as interrupted. Unit: milliseconds.

【Hybrid strategy】: Both RSSI signal and Ping delay are used; if either strategy condition is met, the dial-up connection will be judged as interrupted.


【Network disconnection restart】: Mobile network connectivity detection; disabled by default, to be configured according to specific circumstances;

【PCIe dial-up】: Disabled by default; when enabled, the SIM dial-up method will be PCIe dial-up;

4.5.1.1 Auto network (default)

The default network mode of the mobile network of the device is "automatic" mode, that is, the device will automatically identify the matching network according to the overlay network mode, signal strength, and network mode supported by the SIM card used by the surrounding operator base stations. If there is a 4G signal around, it will automatically match the 4G network first; when there is no 4G network, it will automatically recognize and switch to the 3G network; when the 3G network signal is poor or there is no network, it will automatically switch to the 2G network.

Specific operation: select "Basic Network" --- "Mobile Network" --- "3GWAN1" --- "Basic Settings", select "Network Type", as follows:



4.5.1.2 Lock the network (4G/3G/2G)

Specific operation: select "Basic Network" --- "Mobile Network" --- "Basic Settings", change the "Network Type" to 4G mode, and save the dial-up networking information ("System Status" --- "Overview" --- "3G WAN1 (mobile network) status").

As follows:

The screenshot displays the ZLWL Industrial 4G Router configuration interface. The left sidebar shows the navigation menu with 'Mobile Network' selected. The main content area is divided into two tabs: 'General Setup' and 'Advanced Settings'. In the 'General Setup' tab, the 'Network Type' dropdown is set to '4G', which is highlighted with a red box. The 'Advanced Settings' tab shows various configuration parameters like 'Protocol' (set to 'DHCP client'), 'APN' (set to 'cmnet'), and 'Authentication Type' (set to 'CHAP').

Below this, the 'System Status' tab is selected, showing the 'Overview' section. The 'Status' table provides general information about the router, including its name (M2M), firmware version (Premium Wireless Router v2.2.201124), and hardware details (Product Name: ZR2740S, Product ID: 1120ZR22103110004, MAC Address: 34:0a:68:25:b5:5e, WAN Mode: 3G/4G and Wired). The '4G WAN Status' table shows the current network connection, with the 'Network Operator' field set to 'China Mobile' and 'LTE TDD', also highlighted with a red box.

4.5.2 PPP Dial

The routing device itself also supports PPP dial-up mode, you can try to switch to use this dial-up mode. (This way of dialing generally does not need to manually configure the SIM card APN information. The device will automatically recognize the different APN information of the three major operators when dialing. Dialing failed).

Specific operation: select "Basic Network" --- "Mobile Network" --- "3GWAN1" --- "Basic Settings", select the protocol type "PPP" and confirm the replacement protocol. as follows:

The screenshot displays two views of the ZLWL Industrial 4G Router's web-based configuration interface. Both views are for the '3GWAN1' interface under the 'Mobile Network' section.

Top View (General Setup):

- Left Sidebar:** Shows navigation categories: System Status, Basic Network, Switch, Hostnames, Static Routes, Wired Network, **Mobile Network** (selected), Wireless Network, Static address, Advanced Network, VPN Configuration, and System Management.
- Header:** Overview, Wired Network, Mobile Network (selected), Tab operation.
- Content:** '3GWAN1' interface configuration. The 'General Setup' tab is active. It shows the following status and configuration:
 - Status:** Uptime: 0h 1m 2s, MAC: 9A:63:88:63:50:F2, RX: 122.97 KB (1796 Pkts.), TX: 109.75 KB (2016 Pkts.), IPv4: 10.91.136.68/24.
 - Protocol:** PPP (selected).
 - Buttons:** 'Really switch protocol?' and a prominent red 'SWITCH PROTOCOL' button.

Bottom View (Advanced Settings):

- Left Sidebar:** Same as the top view.
- Header:** Overview, Wired Network, Mobile Network (selected), Tab operation.
- Content:** '3GWAN1' interface configuration. The 'Advanced Settings' tab is active. It shows the following configuration:
 - Status:** RX: 0 B (0 Pkts.), TX: 0 B (0 Pkts.), IPv4: 10.91.136.68/24.
 - Protocol:** PPP (selected).
 - Fields:** PIN, Network Type (Automatic), APN (cmnet), PAP/CHAP username, PAP/CHAP password, Service Type (UMTS/TDS-CDMA/GPRS), Dial number (*99#, Authentication Type (Automatic), Local IP Address, and ICMP Check (Disable)).
 - Note:** A note at the bottom states: "If a local IP address is specified with this option, pppd will not accept a different value from the peer in the IPCP negotiation, unless the ipcp-accept-local options are given, respectively."

4.5.2.1 Automatic network

See for details [4.5.1.1](#)

4.5.2.1 Lock the network (4G/3G/2G)

See for details [4.5.1.2](#)

Notice:

- 1) For the use of APN IoT card or VPDN dedicated network card, please fill in the APN access point information and PAP/CHAP user name and password correctly, otherwise the system cannot complete dial-up networking.
- 2) For the VPDN private network card scenario, it is generally not allowed to access the external network. Please log in to the device page and find the "High Level Network"---"Network Monitoring", turn off this function or modify the default ping address to be a valid and connectable other private network address, otherwise it will cause the device to periodically restart about 10 minutes.

4.6 Wireless Network


The following mainly introduces two commonly used wireless working modes.

Access point AP mode: This working mode is to use the router as a wireless transmitting point, which can provide mobile phones, laptops or other wireless terminals to connect to the Internet through wireless means (Wi-Fi has no password by default before V2.1, and it is strongly recommended for the safety of the device. Please set the WiFi password when the customer uses the device; after the V2.1 version, the default WiFi password is admin123(Factory pre-configuration can be customized according to user requirements.)). Specific operations such as [4.6.1](#)。

Client mode: This mode refers to the use of the routing device as a wireless client, which can enable itself to have networking capabilities by searching and joining other wireless hotspots around it, that is, wireless bridging. Specific operations such as [4.6.2](#).

4.6.1 AP mode

Specific operation: select "Basic Network" --- "Wireless Network" --- "Wireless Overview" to check and confirm. as follows:



Click the Add button to add a WiFi interface, which can be used to configure the access point AP or client mode.

4.6.1.1 Device Configuration

Click the "Edit" button on the right of "Wireless Profile" and enter "Device Configuration" to configure the basic and advanced settings of wireless WiFi.

4.6.1.1.1 Basic Settings

Through the "Basic Settings" option, you can configure the wireless network (WiFi) switch, wireless channel selection and radio power adjustment, as follows;

4.6.1.1.2 Advanced Settings

Through the "advanced settings", you can set the country code, distance optimization and other settings. as follows:


4.6.1.2 Interface Configuration

Click the "Edit" button on the right of the wireless profile and then enter the "Interface Configuration".

4.6.1.2.1 Basic Settings

Through the "Basic Settings" option, you can set the WiFi mode, wireless ESSID (hotspot name), working mode, whether to hide the ESSID name, and enable WMM


mode, etc. as follows:



The screenshot shows the 'Wireless Network' configuration page. The 'Mode' dropdown is set to 'Access Point'. The 'ESSID' field contains 'ZR2740S-25b5e'. Other settings like 'Distance Optimization', 'Fragmentation Threshold', and 'RTS/CTS Threshold' are also visible.

4.6.1.2.1 WiFi Password Setting


Through the "Wireless Security" option, you can set the wireless encryption method (the new version defaults to WPA-PSK/WPA2 Mixed Mode mixed encryption), algorithm and secret key settings, etc. (the password is at least 8 digits, the default is Admin@123), and the rest of the settings are generally default That's it.



The screenshot shows the 'Wireless Security' configuration page. The 'Encryption' dropdown is set to 'WPA-PSK/WPA2-PSK Mixed Mode'. The 'Cipher' dropdown is set to 'auto'. The 'Key' field contains '*****'. Other settings like '802.11n Fast Transition' and '802.11w Management Frame Protection' are also visible.


4.6.1.2.3 Black and white list settings

Through the "MAC filtering" option, you can set whether to enable MAC address filtering (disabled by default), "allow only in the list (whitelist: accessible)" or "only allow outside the list (blacklist: no access)". as follows:



4.6.1.2.4 Advanced Settings


Through the "Advanced Settings" option, you can set whether to isolate the client, etc., as follows:



4.6.2 Client Mode


You can scan to join other wireless hotspots and set the method of obtaining an IP address (DHCP (default) or static address). as follows:

1) Specific operation: Select "Basic Network" --- "Wireless Network" --- "Wireless Overview", click the "Scan" button on the right to start searching for other wireless hotspots around, as follows:



2) Select the wireless hotspot that needs to be connected, click "join network", check "reset wireless configuration" and set the password of the wireless hotspot and the name of the new network (the default is sufficient), and finally click "submit", the page will jump Go to the "Interface Configuration" --- "Basic Settings" page (you can set the protocol (wireless IP address acquisition method) to DHCP (default) or

static address method), the rest of the settings can be defaulted, and finally click "Save Application", as follows:



Join Network: Wireless Scan

Signal	SSID	Channel	Mode	BSSID	Encryption	Action
90%	ZLWL-HUAWEI	1	Master	04:95:E6:5C:EC:F1	mixed WPA/WPA2 - PSK	JOIN NETWORK
82%	ZR2721S-24b8ec	11	Master	34:0A:68:24:B8:EE	mixed WPA/WPA2 - PSK	JOIN NETWORK
80%	TP-LINK_AE08	6	Master	74:05:A5:7C:AE:08	mixed WPA/WPA2 - PSK	JOIN NETWORK
80%	ZP3721S-249a92	11	Master	34:0A:68:24:9A:94	mixed WPA/WPA2 - PSK	JOIN NETWORK
77%	SDI	11	Master	B8:80:35:42:A1:80	mixed WPA/WPA2 - PSK	JOIN NETWORK
62%	ChinaNet-NnkJN	1	Master	F0:92:84:85:B7:09	mixed WPA/WPA2 - PSK	JOIN NETWORK
55%	hidden	11	Master	B8:80:35:42:A1:80	WPA2 - PSK	JOIN NETWORK
52%	SDI-2	11	Master	28:6C:07:52:6C:6B	mixed WPA/WPA2 - PSK	JOIN NETWORK

Joining Network: "ZLWL-HUAWEI"

Replace wireless configuration Check this option to delete the existing networks from this radio.

WPA passphrase Specify the secret encryption key here.


Name of the new network The allowed characters are: A-Z, a-z, 0-9 and _.

Create / Assign firewall-zone Choose the firewall zone you want to assign to this interface. Select unspecified to remove the interface from the associated zone or fill out the create field to define a new zone and attach the interface to it.


BACK TO SCAN RESULTS **SUBMIT**

4.6.2.1 Client DHCP (default)

After filling in the password and submitting, jump to the WiFi interface configuration page, "Interface Configuration" --- "Basic Settings", the "Protocol" defaults to "DHCP", and then save the application.



The screenshot shows the 'Wireless Network' configuration page. The 'General Setup' tab is selected. The 'Mode' dropdown is set to 'Client'. The 'SSID' field contains 'ZLWL-HUAWEI'. The 'BSSID' field shows '04:95:E6:5C:EC:F1'. The 'Protocol' dropdown is set to 'DHCP'. A red box highlights the 'Mode' and 'SSID' fields. A warning message at the bottom states: 'WARNING: This will disable DHCP for LAN'.



The screenshot shows the 'Wireless Security' configuration page. The 'Encryption' dropdown is set to 'WPA2-PSK'. The 'Cipher' dropdown is set to 'auto'. The 'Key' field contains a redacted password. A red box highlights the 'Encryption' and 'Key' fields. At the bottom right are 'SAVE & APPLY' and 'RESET' buttons.

After clicking to save the application, select "System Status" --- "Overview" --- "Wireless" to check that the wireless client mode has been successfully connected at this time, as follows:



The screenshot shows the ZLWL Industrial 4G Router web interface. The left sidebar has a blue header 'System Status' and a 'Basic Network' section with 'Switch', 'Hostnames', 'Static Routes', 'Wired Network', 'Mobile Network' (selected), 'Wireless Network', 'Static address', and 'Advanced Network' (with 'Overview' selected). The main content area has tabs 'Overview' (selected), 'Mobile Network', and 'Wireless Network'. The 'Overview' tab shows 'radio0: Client "ZLWL-HUAWEI"'. The 'Wireless Overview' section shows a 'Generic 802.11bgn Wireless Controller' with a progress bar at 0% and a status of 'Collecting data...'. Buttons for 'RESTART', 'SCAN', 'ADD', 'DISABLE', 'EDIT', and 'REMOVE' are available. The 'Associated Stations' table lists a client with MAC address 04:95:E6:5C:EC:F1, signal/noise -50/-95 dBm, and rates 78.0 Mbit/s, 20MHz, MCS 12 and 6.5 Mbit/s, 20MHz, MCS 0. The 'Overview' tab also shows memory usage: Free (66220 kB / 124740 kB (53%)) and Buffered (7476 kB / 123740 kB (6%)). The 'DHCP Leases' section shows a lease for 'my_device' with IP 192.168.1.152, MAC 00:0E:4C:21:19:A0, and lease time 11h 58m 50s. The 'Wireless' section shows the 'Generic 802.11bgn Wireless Controller (radio0)' with a red box highlighting its configuration: SSID: ZLWL-HUAWEI, Mode: Client, Channel: 1 (2.412 GHz), Bitrate: 5.6 Mbit/s, BSSID: 34:0A:68:25:BB:60, Encryption: WPA2 PSK (TKIP,CCMP), Address: 192.168.10.140, Gateway: 192.168.10.1, DNS 1: 202.96.134.33, and Uptime: 0h 0m 53s. The 'Associated Stations' table shows one station with MAC 04:95:E6:5C:EC:F1, signal -48 dBm, noise -95 dBm, RX rate 52.0 Mbit/s, MCS 11, 20MHz, and TX rate 6.5 Mbit/s, MCS 0, 20MHz.

4.6.2.1 Client static address

You can scan to join WiFi, fill in the password and submit it, and then jump to the WiFi interface configuration page. In "Interface Configuration" --- "Basic Settings", select "Protocol" as "Static Address", and then enter the IP address, subnet mask, Save the application after the gateway and DNS server.



System Status > Overview X Mobile Network X Wireless Network X

Basic Network > Switch Hostnames Static Routes Wired Network Mobile Network Wireless Network

Static address

Advanced Network > VPN Configuration > System Management > Logout

Interface Configuration

General Setup Wireless Security Advanced Settings

Mode: Client

ESSID: ZLWL-HUAWEI

BSSID: 04:95:E6:5C:EC:F1

Protocol: Static address

IP4 address: 192.168.10.178

IP4 netmask: 255.255.255.0

IP4 gateway: 192.168.10.1

Use custom DNS servers: 114.114.114.114

Bridge:

WARNING: This will disable DHCP for LAN

BACK TO OVERVIEW SAVE & APPLY RESET

If you used "Protocol" as "DHCP" when scanning and joining before, now you need to change it to a static IP address. Specific operation: Select "Basic Network" --- "Wireless Network" --- "Wireless Profile", click the "Edit" button on the right, enter the interface configuration and select "Protocol" to change to "Static Address". After the configuration is as above:

System Status > Overview X Mobile Network X Wireless Network X

Basic Network > Switch Hostnames Static Routes Wired Network Mobile Network Wireless Network

Static address

Advanced Network > VPN Configuration > System Management > Logout

radio0: Client "ZLWL-HUAWEI"

Wireless Overview

radio0: Generic 802.11bgn Wireless Controller
Channel: 1 (2.412 GHz) | Bitrate: 19.5 Mbit/s

92% SSID: ZLWL-HUAWEI | Mode: Client
BSSID: 34:0A:68:25:88:60 | Encryption: WPA2 PSK (TKIP CCMP)

RESTART SCAN ADD

Associated Stations

Network	MAC-Address	Host	Signal / Noise	RX Rate / TX Rate
Client "ZLWL-HUAWEI" (wlan0)	04:95:E6:5C:EC:F1	?	-46 / -95 dBm	52.0 Mbit/s, 20MHz, MCS 11 19.5 Mbit/s, 20MHz, MCS 2

System Status > Overview X Mobile Network X Wireless Network X

Overview

Routes System Log Kernel Log Realtime Graphs Load Balancing

Basic Network > Advanced Network > VPN Configuration > System Management > Logout

DHCP Leases

Hostname	IP Address	MAC-Address	Leasetime remaining
my_device	192.168.1.152	00:00:4C:21:19:A0	11h 59m 12s
PC-201911141944	fd:5d:0e:25:56:50/128	00:01:00:01:25:5e:fc:80:00:c2:98:57:3e	11h 59m 11s

Wireless

Generic MAC80211 802.11bgn Wireless Controller (radio0)

SSID: ZLWL-HUAWEI
Mode: Client
Channel: 1 (2.412 GHz)
Bitrate: 19.5 Mbit/s
BSSID: 34:0A:68:25:88:60
Encryption: WPA2 PSK (TKIP CCMP)

Address: 192.168.10.178
Gateway: 192.168.10.1
DNS 1: 114.114.114.114
Uptime: 0h 0m 56s

Associated Stations

MAC-Address	Signal	Noise	RX Rate	TX Rate
04:95:E6:5C:EC:F1	-47 dBm	-95 dBm	52.0 Mbit/s, MCS 11, 20MHz	19.5 Mbit/s, MCS 2, 20MHz

4.7 Static address

The static address function is used to assign a fixed IPv4 address to a host with a specified MAC address, that is, the host device MAC-IP binding, and it can also customize the device host name.

Select "Basic Network" --- "Static Address" and click the "Add" button to set the host name, MAC address, IPv4 address, lease period, etc., as follows:

Hostname	MAC-Address	IPv4-Address	Lease time	DUID	IPv6-Suffix (hex)
my123	00:E0:4C:21:19:A0 (my_device.la)	192.168.1.152	infinite		

Buttons: ADD, DELETE, SAVE & APPLY, RESET

5. Advanced Network


5.1 QoS

Here you can configure some specific QoS service quality rules, such as limiting the rate of each interface of the device or sorting different traffic data packets.

Target	Source host	Destination host	Protocol	Ports	Number of bytes	Comment
priority	all	all	all	22,53	ssh, dns	<input type="button" value="DELETE"/>
normal	all	all	TCP	20,21,25,60,110,443,993,95	ftp, smtp, http(s), imap	<input type="button" value="DELETE"/>
express	all	all	all	5190	AOL, iChat, ICQ	<input type="button" value="DELETE"/>

5.2 DMZ

The network attributes used for the WAN interface of the routing device (such as with a public IP address) forward the full port of the external network to the internal network host behind the firewall, so that the internal service resources of the network can be accessed quickly and efficiently. Examples are as follows:



5.3 Firewall

The firewall configuration is used to set certain rules for the inbound and outbound traffic of the routing system so as to effectively protect the security of the system.

5.3.1 Basic Settings

It is mainly used to set the entry and exit data access rules of different interface areas of the routing system and set related SYN-flood defense, etc. It is generally defaulted and does not need to be changed.



5.3.2 Communication rules

This is mainly used to define data packet transmission strategies between different areas, such as allowing or denying communication between some hosts. For details, you can also click "New Forwarding Rule" to add a user-defined communication rule policy, as follows:

For example: create a new forwarding rule "blacklist" to restrict devices connected to the router from being able to access the Internet based on the MAC address. as follows:

The parameters need to be set as follows, and the rest can be defaulted.


[Agreement]: Any;

[Source MAC address]: Access router LAN LAN host device MAC address, the example access router host MAC address is 00-50-56-2B-95-F0 (because the IP address will change directly);

[Action]: Reject;


5.3.3 Domain name filtering

Here you can set the black and white list of the network domain addresses to be accessed, thereby denying or allowing the router system to communicate with these addresses, as follows:



5.3.4 Keyword filtering

Here, you can configure keyword filtering to reject the routing system and certain specified network communications, as follows:




5.4 Portal authentication (optional)

This function is used to set advertising routing authentication parameters. Click "Advanced Network"- "Portal Authentication" to configure as follows:

5.4.1 General arrangement

You can configure whether it is enabled, the mode of obtaining advertisement files, and the redirection address after authentication.




The configuration instructions are as follows:

[Enable] Check whether to enable the advertising routing function.

[Mode] You can choose the authentication file upload mode, which is uploaded locally by default.

[Jump address after authentication] The default is none, you can set it yourself.

5.4.1.1 Local Upload




[Format] Upload a compressed package of certification files in *.zip format

5.4.1.2 Download file from URL server address

[Address] Fill in the URL server to store the htdocs advertisement file path


(support http, https);

[Page update] means that when the htdocs advertisement file of the URL server changes, the advertising router will re-download the new htdocs file from the URL server. It is recommended to check it. After checking, the router background will check the server file every 5 minutes and update it synchronously.



5.4.2 counter


It can be used to set the timeout period of connected devices and the maximum number of device connections.



[Session timeout] refers to the total time that wireless terminals such as mobile phones can connect to the router after WiFi access is authenticated. If this time is exceeded, the terminal will be disconnected and need to be re-authenticated. The default value is 120 minutes, which is 2 hours.

[Maximum number of customers] refers to the number of wireless terminals that support WiFi authentication for connecting to the router. When this value is exceeded, the newly added wireless terminal cannot pass the authentication. The default value is 25.

5.4.3 Filter




[Uncertified device] refers to a wireless terminal that is not connected to the router with WiFi certification or certification-free, and there are no restrictions on use by default.

[Authenticated device] refers to the network usage restrictions for wireless terminals after connecting to the route WiFi authentication, such as the restriction of the destination ip address or access port, all are allowed by default, and there is no restriction.

[Authentication-free device MAC address] means that after filling in the device's network card mac address, the wireless terminal does not need to be authenticated after connecting to the routed WiFi, and can directly access the network.

[Ignore wired devices] After checking, the system will ignore LAN access devices for authentication, and you can directly access the network.


5.4.4 other



[Debug] Switch to different log debugging sectors (none, error, information, debugging), the router system log will correspondingly display the corresponding log information;

5.5 Repeater

This function is used to forward TCP/UDP to other network locations. as follows:



5.6 Port forwarding

This function is used to map the service resources of the internal host to the external access area of the device (usually a public IP address or an address that can be directly accessed), and at the same time makes the access to the internal service resources more secure. as follows:



System Status >
Basic Network >
Advanced Network >
QoS
DMZ
Firewall
Portal Captive
Repeater
Port Forwards
Static NAT
SmartLink
MCM Platform

Firewall - Port Forwards
Allows remote computers on the Internet to connect to a specific computer or service within the private LAN.

Port Forwards

Name	Match	Forward to	Enable
			This section contains no values yet

New port forward

Name	Protocol	External zone	External port	Internal zone	Internal IP address	Internal port
Forward8000	TCP+UDP	wan	8000	lan	192.168.1.152	8000

ADD **SAVE & APPLY** **RESET**

System Status >
Basic Network >
Advanced Network >
QoS
DMZ
Firewall
Portal Captive
Repeater
Port Forwards
Static NAT
SmartLink

Firewall - Port Forwards
Allows remote computers on the Internet to connect to a specific computer or service within the private LAN.

Port Forwards

Name	Match	Forward to	Enable
Forward8000	IPv4-tcp, udp From any host in wan Via any router IP at port 8000	IP 192.168.1.152 port 8000 in lan	<input checked="" type="checkbox"/> EDIT DELETE

New port forward

Name	Protocol	External zone	External port	Internal zone	Internal IP address	Internal port
Name	TCP+UDP	wan		lan		

ADD

[Name]: The name of the custom rule;

[Agreement]: Select rule agreement, generally ALL;

[External area]: select WAN area;

[External port]: Fill in the port for forwarding access to the external area;

[Internal Area]: Select the area for internal forwarding, here is the LAN area;

[Internal address]: Fill in the internal host address after forwarding, which can be filled in specifically;

[Internal port]: Fill in the port forwarded and accessed by the internal host, which can be filled in specifically;

5.7 Static NAT

This function allows remote computers on the Internet to connect to specific computers or services in the internal network, and the device supports 1-to-1 or many-to-one static nat functions.


5.8 Smarklink

Smart IoT is composed of two parts: [General] and [Advanced].

[General] The interface mainly displays basic information such as user configuration mode configuration, connection configuration, and serial port configuration.

[Advanced] It mainly displays the advanced configuration of the serial port and other information.


5.8.1 General



5.8.1.1 Mode configuration

Click Add to create and use a new usage mode, and you can choose to use the created connection.

Note: Multiple modes cannot use the same working mode as the connection of the universal serial port. (The universal serial port is the physical COM port of the router device.)



5.8.1.2 Connection configuration

Uplink device settings:

Enabled	Name	Working Mode	Target Address	Status	Conns	Protocol
√	Cloud	TCP Server	30001	Listening	0	Pass-Through
√	UART_DEV	UART	COM1	Connected	1	Pass-Through

The parameter description is as follows:

[Enable]: After checking, enable the serial port function;

[Name]: It is empty by default and can be named;

[Work Agreement]: Choose the corresponding work mode according to actual needs;

[Monitor port]: TCP port, this item is related to the specific working mode;

[Protocol]: Transparent transmission mode;

[Heartbeat]: Not checked by default;

[Heartbeat interval]: can be set specifically, the unit is second;

[Heartbeat content]: It can be set specifically, and the heartbeat content in the corresponding format must be filled in;

[Save and apply]: The configuration will take effect after saving and will be displayed in the general interface;

Downstream device settings:

The screenshot shows the ZLWL Industrial 4G Router configuration interface. The left sidebar navigation includes: System Status, Basic Network, Advanced Network (with QoS, DMZ, Firewall, Portal Captive, Repeater, Port Forwards, Static NAT, Smartlink, M2M Platform, Network Monitor, Dynamic DNS). The 'Smartlink' option is highlighted. The main content area has tabs: Port Forwards, Overview, Smartlink (selected), and System Log. The 'Smartlink' tab has sub-tabs: General, Collection, Advance. The 'Mode Configuration' section shows 'Enabled' checked, 'Uplink Device' as 'Cloud', and 'Downlink Device' as 'UART_DEV' with 'EDIT' and 'DELETE' buttons. The 'Connection Configuration' section shows a table with a row for 'UART_DEV' (Name: 'UART_DEV', Working Mode: 'UART', Target Address: 'COM1', Status: 'Connected', Conns: '1', Protocol: 'Pass-Through') with 'EDIT' and 'DELETE' buttons. The bottom window is a detailed configuration for 'UART_DEV' with fields: Name (UART_DEV), Working Mode (UART), Protocol (Pass-Through selected from a dropdown menu with options: Pass-Through, Custom Proto, Modbus JSON, Modbus IOT), and Device Name. Buttons at the bottom are 'BACK TO OVERVIEW', 'SAVE & APPLY', and 'RESET'.

5.8.1.3 Serial port configuration

Click the edit button to enter the COM port configuration interface.

The interface parameters are described as follows:

[Baud rate]: The default is 115200, which can be set specifically;

[Data bit]: The default is 8, which can be set specifically;

[Stop bit]: The default is 1, which can be set specifically;

[Check Digit]: The default is NO, which can be set specifically;


[Flow Control]: The default is NONE, which can be set specifically;

[Sub-packing interval]: The default is 60, which can be set specifically;

[Sub-package length]: The default is 1460, which can be set specifically;

5.8.2 advanced

Mainly configure the opening and closing of the Smartlink function, the opening and closing of debugging, the size, number, priority, download, etc. of log files. as follows:



The advanced parameters are described as follows:

[Open]: Smart IoT switch.

[Debug]: Not checked by default.

[TCP keep-alive idle time]: The default is 60s, which can be set specifically.

[TCP keep-alive detection interval]: The default is 3s, which can be set specifically.

[Maximum times of TCP keep-alive detection]: The default is 3 times, which can be set specifically.

[Number of retained log files]: The default is 2, which can be set specifically.

[Log file size]: The default is 200KB, and it is recommended not to exceed 3000KB.


[Log Priority]: Default information, which can be selected specifically.

[Log file]: Download button.

5.8.3 Operating mode

Smartlink supports a total of 12 modes to meet the needs of different scenarios in the project. It can be flexibly configured according to the actual needs of the site. The general serial port mode is the physical COM port of the router.


Select "Advanced Network" --- "Smart IOT" --- "General" --- "Connection Configuration" --- "Edit", select "Work Mode". as follows:



5.8.4 Custom protocol

Smartlink usage protocol supports the use of custom protocols to meet the needs of different scenarios. It can be flexibly configured according to the actual needs of the site.

Select "Advanced Network" --- "Smartlink" --- "General" --- "Connection Configuration" --- "Edit", select "Protocol". as follows:



The screenshot shows the configuration interface for the ZLWL Industrial 4G Router. The left sidebar lists various network settings. The main panel is titled 'Smartlink' and is currently set to 'UART_DEV'. The configuration includes:

- Enabled:** Checked
- Name:** UART_DEV
- Working Mode:** TCP Server
- Listen Port:** 30001
- Protocol:** Custom Proto
- Msg Prefix:** (Input field)
- Msg Suffix:** (Input field)
- Msg Length Zone Byte:** 0 (bytes)
- Msg Seq:** 0 (bytes)
- Msg CRC:** NULL
- DeviceID:** 1120ZR21808270188

[Message prefix]: a standard hexadecimal string starting with 0x or 0X, up to 4 bytes;

[Message length byte]: 0/1/2 byte setting can be set by yourself;

[Message sequence number]: default 0 byte, support 0/1/2 byte setting;

[Device ID]: ASCII and hexadecimal strings can be supported. If it is a hexadecimal string, it must be a standard hexadecimal string starting with 0x or 0X, and the maximum length is 16 bytes;

[CRC check]: The default is null, which can be set according to actual use;

[Message suffix]: a standard hexadecimal string beginning with 0x or 0X, maximum 4 bytes;

[Enable Heartbeat]: Heartbeat packet function settings, including two parameters, heartbeat content and heartbeat sending interval, which are not enabled by default.

5.8.5 Configuration example

5.8.5.1 TCP server

Example description

In the TCP server mode, the router configures an IP port number (monitoring the local port) as a TCP server, and passively waits for the remote host to connect. After the remote host initiates a connection request and establishes a connection with the router, the remote host can realize two-way transparent transmission through the network connection and the serial port. The remote host can read or send data to a serial device at the same time.

Example steps

Router (TCP server) parameters:

WAN port IP address: 192.168.10.122

Listening port: 6800

Serial port configuration parameters:

Physical interface Baud rate Data bit Stop bit Parity bit Flow control


COM1 115200 8 1 None None

Remote PC (TCP client) parameters:


IP address: 192.168.10.192

Step 1: Configure the WAN port IP address

Wired network>WAN>click protocol (select static address)>click to switch protocol



Configure the IPV4 address, subnet mask, and IPV4 gateway, and click the Save and Apply button in the lower right corner to save the configuration.



Step 2: Configure the serial port configuration

Smartlink> Click the "Edit" button of COM1. The serial port parameter can be configured.



Enter the configuration interface to modify the baud rate, data bit, stop bit and other parameters according to actual needs. The "Save and Apply" button in the lower right corner will save and take effect.

5.8.5.2 TCP Client

Example description

In the TCP client mode, the router host IP and port number actively establish a TCP protocol connection with the remote PC, and the router can realize bidirectional transmission to the transparent mode through the network connection and the remote PC. The PC can send and receive data to a serial device at the same time.

Example steps

Router (TCP client) parameters:

WAN port IP address: 192.168.10.122

Server address: 192.168.10.192

Server port: 6800

Serial port configuration parameters:

Physical interface Baud rate Data bit Stop bit Parity bit Flow control

COM1 115200 8 1 None None

PC (TCP server) parameters:

IP address: 192.168.10.192

Step 1: Configure the WAN port IP address

Wired network>WAN>click protocol (select static address)>click to switch protocol

Configure IPv4 address, subnet mask, IPv4 gateway.

Step 2: Configure the serial port configuration

Smartlink> Click the edit button in the serial port configuration bar. The serial port parameter can be configured.



Enter the configuration interface to modify the baud rate, data bit, stop bit and other parameters according to actual needs.

System Status >
Basic Network >
Advanced Network >
 QoS
 DMZ
 Firewall
 Repeater
 Port Forwards
 Static NAT
 Smartlink
 M2M Platform
 Network Monitor
 Dynamic DNS
 SNMP Service
VPN Configuration >
System Management >
Logout

Smartlink >

General Collection Advance

COM1

Speed	115200
Data Bit	8
Stop Bit	1
Parity	None
Flow Control	None
Enable Frame	<input checked="" type="checkbox"/>
Frame Interval	60
Frame Length	1460
bytes	

BACK TO OVERVIEW SAVE & APPLY RESET

Premium Wireless Router v2.3.210811

Step 3: Configure the server address and port for receiving data

System Status >
Basic Network >
Advanced Network >
 QoS
 DMZ
 Firewall
 Repeater
 Port Forwards
 Static NAT
 Smartlink
 M2M Platform
 Network Monitor
 Dynamic DNS
 SNMP Service
VPN Configuration >
System Management >
Logout

Smartlink >

General Collection Advance

Mode Configuration

Enabled	Cloud	Uplink Device	Downlink Device
<input checked="" type="checkbox"/>	Cloud	Cloud	UART_DEV

ADD EDIT DELETE

Connection Configuration

Enabled	Name	Working Mode	Target Address	Status	Coms	Protocol	EDIT	DELETE
<input checked="" type="checkbox"/>	Cloud	TCP Server	30001	Listening	0	Pass-Through	EDIT	DELETE
<input checked="" type="checkbox"/>	UART_DEV	UART	COM1	Connected	1	Pass-Through	EDIT	DELETE

ADD EDIT DELETE

Serial Configuration

Interface	Speed	Data Bit	Stop Bit	Parity	Flow Control	EDIT
COM1	115200	8	1	None	None	EDIT

SAVE & APPLY RESET

System Status >
Basic Network >
Advanced Network >
 QoS
 DMZ
 Firewall
 Repeater
 Port Forwards
 Static NAT
 Smartlink
 M2M Platform
 Network Monitor
 Dynamic DNS
 SNMP Service
VPN Configuration >
System Management >
Logout

Smartlink >

General Collection Advance

Cloud

Enabled	<input checked="" type="checkbox"/>
Name	Cloud
Working Mode	TCP Client
Server Address	192.168.10.192:6900
Protocol	Pass-Through
Enable Heartbeat	<input type="checkbox"/>

BACK TO OVERVIEW SAVE & APPLY RESET

Premium Wireless Router v2.3.210811

5.8.5.3 UDP Server

Slightly (same as TCP server mode, the difference is that UDP server mode uses UDP protocol to build network connection)

5.8.5.4 UDP Client

Slightly (same as TCP client mode, the difference is that UDP client mode uses UDP protocol to build network connections)

5.8.5.5 Real serial port mode

Example description

In the real serial port mode, the router connects to the virtual serial port of the remote PC. The virtual serial port tool establishes a transparent network transmission connection between the host and the serial device in the operating system, and maps the router's serial port to the host's local virtual serial device according to the parameters such as the router IP address and serial number configured by the user to realize the real serial port and virtual Transparent transmission between serial ports.

Example steps

Router (real serial port) parameters:

WAN port IP address: 192.168.10.122

Router port: 30001 (fixed)

Serial port configuration parameters:

Physical interface Baud rate Data bit Stop bit Parity bit Flow control

COM1 115200 8 1 None None

PC parameters:

IP address: 192.168.10.192

Step 1: Configure the WAN port ip address


Omit (same as above)

Step 2: Configure the serial port configuration

Omit (same as above)

Step 3: Connection configuration

Configuration Enable check, name (can be empty), working mode selection: real serial port mode



5.8.5.6 MQTT Client

Example description

Two MQTT clients are similar to the process of mailing letters between two people. One party publishes a message, and the other party receives the message after subscribing.

Example steps

Serial port configuration parameters:

Physical interface Baud rate Data bit Stop bit Parity bit Flow control

COM1 115200 8 1 None None

Serial port configuration parameters:

Physical interface Baud rate Data bit Stop bit Parity bit Flow control

COM1 115200 8 1 None None


step 1:

Configure serial port configuration

Omit (same as above)

Step 2: Connection configuration

Configuration Enable check, name (can be empty), working mode selection: MQTT client



[Server address] Fill in the MQTT server address and port (server address: port).

[Protocol] The default transparent transmission mode, you can choose by yourself;

[Username/Password] The MQTT server decides whether it is required or not. If there is, it needs to be filled in.

[Subscribe/Report Subject] The subject address for mutual communication can be set by yourself.

[Qos] Quality of service, the default is 0, you can choose to set 1, 2.

[Customer ID] Default device serial number.

[MQTT keep-alive period] MQTT keep-alive period, the default is 60 seconds.

[Device Mode] The default transparent transmission mode can be selected by yourself.

[Heartbeat] Check to enable.

[Heartbeat interval] The unit is second, which can be set by yourself.

[Heartbeat content] ASCII code and hexadecimal string can be set by yourself.

5.8.5.7 Modbus RTU to TCP master-slave communication

Please contact technical support to assist in debugging.

5.8.5.8 Modbus TCP master-slave communication


Please contact technical support to assist in debugging.

5.9 M2M Cloud platform

The user scenario of this function is: the router connects to the cloud server management platform through the Internet, and the user can realize remote view

management of the router, remote firmware upgrade, remote configuration, log download and view without going to the site.

The functional parameters are described below:



[Start M2M Platform Control]: Enable or disable the platform connection;

[Heartbeat Interval(s)]: The heartbeat interval between the router client and server platform (default: 15s);

[Heartbeat timeout times]: The router client reports the number of failed heartbeat packets (if it exceeds this number, the router is considered to have failed to connect to the platform). The default is 10 times.

[Net Status Interval(s)]: The interval at which the router reports its online status to the server platform (default 120s).

[Server IP:Port(New Platform)]: Server platform address and port configuration;

[Status]: The status of the router connecting to the cloud platform;


5.10 Load Balancing (optional)

The load balancing function (MWAN3) is mainly to deploy the interface traffic of different network interfaces of the router system (such as wired WAN, 3G/4G mobile network, WiFi client, etc.) according to certain policy rules, mainly including traffic balancing or switching backup.

The overall features of load balancing will be described below.

Note: For scenarios that use virtual private network functions (such as PPTP/2LTP/IPSEC, etc.), please turn off the device load balancing function to avoid causing the virtual private network to fail.

Load balancing is enabled by default in the system (different versions, different), select "System Status" --- "Overview" to view the real-time status of load balancing, as follows:



The screenshot shows the ZLWL Industrial 4G Router's web-based management interface. The left sidebar is a navigation menu with the following items:

- System Status
- Overview
- Router
- System Log
- Kernel Log
- Realtime Graphs
- Load Balancing
- Basic Network
- Advanced Network
- VPN Configuration
- System Management
- Logout

The main content area is titled "Overview" and contains the following sections:

- DHCP Leases:** A table showing two entries with columns: Hostname, IP Address, MAC-Address, and Leasetime remaining.
- Wireless:** Information for "Generic MAC80211 802.11bgn Wireless Controller (radio0)".
 - SSID: ZR2740S-25bb5e
 - Mode: Master
 - Channel: 11 (2.462 GHz)
 - Bitrate: 7Mbps
 - 0% BSSID: 34:0A:68:25:BB:60
 - Encryption: mixed WPA/WPA2 PSK (CCMP)
 - Uptime: 0h 10m 30s
- Associated Stations:** A table with columns: MAC-Address, Signal, Noise, RX Rate, and TX Rate. It displays "No information available".
- Load Balancing:** A section with three cards:
 - Interface: wan** Status: Online Uptime: 0h 9m:24s
 - Interface: wwan** Status: Disabled
 - Interface: 3gwan1** Status: Online Uptime: 0h 9m:5s

5.10.1 Global

Click the "Advanced Network" --- "Load Balancing" --- "Global" tab, which can be used to enable or disable the load balancing function (not enabled by default), as follows:



System Status > Overview X Mobile Network X Wired Network X Wireless Network X Load Balancing X Tab operation ▾

Basic Network >

Advanced Network >

QoS

DMZ

Firewall

Repeater

Port Forwards

Static NAT

SmartLink

M2M Platform

Load Balancing

Globals Interfaces Members Policies Rules

Load Balancing - Globals

Enable

Local source interface Use the IP address of this interface as source IP address for traffic initiated by the router itself

Firewall mask Enter value in hex, starting with 0x

SAVE & APPLY RESET

5.10.2 Interface

Click the "Advanced Network" --- "Load Balancing" --- "Interface" tab to configure specific interface parameters. You can also add other interfaces by clicking the "Add" button in the lower left corner. After clicking "Edit", you can configure and modify the parameters as follows:

System Status > Overview X Mobile Network X Wired Network X Wireless Network X Load Balancing X Tab operation ▾

Basic Network >

Advanced Network >

QoS

DMZ

Firewall

Repeater

Port Forwards

Static NAT

SmartLink

M2M Platform

Load Balancing

Network Monitor

VPN Configuration

System Management

ADD

Globals Interfaces Members Policies Rules

Load Balancing-Interfaces

There are currently 3 of 60 supported interfaces configured

WARNING: Interface wwan are not found in /etc/config/network

Load balancing supports up to 252 physical and/or logical interfaces

Load balancing requires that all interfaces have a unique metric configured in /etc/config/network

Names must match the interface name found in /etc/config/network

Names may contain characters A-Z, a-z, 0-9, and no spaces

Interfaces may not share the same name as configured members, policies or rules

Name	Enabled	Tracking method	Tracking reliability	Ping interval	Interface down	Interface up	Metric	EDIT	DELETE
wan	Yes	ping	1	5s	3	3	10	<input type="button" value="EDIT"/>	<input type="button" value="DELETE"/>
wwan	Yes	ping	1	5s	3	3	—	<input type="button" value="EDIT"/>	<input type="button" value="DELETE"/>
3gwan1	Yes	ping	1	5s	3	3	20	<input type="button" value="EDIT"/>	<input type="button" value="DELETE"/>

SAVE & APPLY RESET

System Status > Overview X Mobile Network X Wired Network X Wireless Network X Load Balancing X Tab operation ▾

Basic Network >

Advanced Network >

QoS

DMZ

Firewall

Repeater

Port Forwards

Static NAT

SmartLink

M2M Platform

Load Balancing

Network Monitor

VPN Configuration

System Management

Logout

Load balancingInterface Configuration - 3gwan1

Enabled

Initial state

Expect interface state on up event

Internet Protocol

Tracking hostname or IP address

This hostname or IP address will be pinged to determine if the link is up or down. Leave blank to assume interface is always online

Tracking method

Tracking reliability

Acceptable values: 1-100. This many Tracking IP addresses must respond for the link to be deemed up

Ping count

Ping size

Max TTL

Check link quality

Ping timeout

Ping interval

Failure interval

[Enable]: Whether to enable interface detection, it is enabled by default.

[Initial state]: Select the state of the interface during initial detection, such as online or offline.

[Internet Protocol]: Optional IPv4, IPv6, default IPv4.

[Tracked host or IP address]: Use ping to detect the destination host to determine whether the device's external network access is normal, and then to further determine whether the interface is online or offline, which is generally a public network or a valid IP.

[Tracking mode]: Ping mode is selected by default.

[Tracking reliability]: Specify how many IP addresses can be pinged when the interface will be considered online, and the default is one.

[Ping count]: the number of times of ping detection.

[Ping size]: The size of the data packet detected by ping, the default is 8 bytes.

[Ping timeout]: How long does it take to ping the external network or there is no response when it is considered as a timeout.

[Ping interval]: How often do you ping the destination host IP.

[Fault detection interval]: The ping interval during fault detection, the default is 5s.

[Failure Recovery Interval]: The ping interval during failure recovery, the default is 5s.

[Interface offline]: When the number of Ping failures reaches this value, the interface will be considered offline, 3 times by default.

[Interface online]: When the number of successful pings reaches this value, the interface that has been considered offline will be Go online again, 3 times by default.

[Refresh Interval Connection Table]: Refresh the global firewall connection tracking table when an interface event is triggered, which is enabled by default.

[Metrics]: Shows the metric of this interface in the configuration.

5.10.3 Member


Click the "Members" tab to view or add the members corresponding to each interface and configure different metric and weight. The system presets 6 member properties by default, as follows:

Name	Interface	Metric	Weight	EDIT	DELETE
wan_m1_w1	wan	1	1	<input type="button" value="EDIT"/>	<input type="button" value="DELETE"/>
wan_m1_w2	wan	1	2	<input type="button" value="EDIT"/>	<input type="button" value="DELETE"/>
wan_m2_w1	wan	2	1	<input type="button" value="EDIT"/>	<input type="button" value="DELETE"/>
wwan_m1_w1	wwan	1	1	<input type="button" value="EDIT"/>	<input type="button" value="DELETE"/>
wwan_m1_w2	wwan	1	2	<input type="button" value="EDIT"/>	<input type="button" value="DELETE"/>
wwan_m2_w1	wwan	2	1	<input type="button" value="EDIT"/>	<input type="button" value="DELETE"/>
3gwan1_m1_w1	3gwan1	1	1	<input type="button" value="EDIT"/>	<input type="button" value="DELETE"/>
3gwan1_m1_w2	3gwan1	1	2	<input type="button" value="EDIT"/>	<input type="button" value="DELETE"/>
3gwan1_m2_w1	3gwan1	2	1	<input type="button" value="EDIT"/>	<input type="button" value="DELETE"/>
3gwan1_m3_w1	3gwan1	3	1	<input type="button" value="EDIT"/>	<input type="button" value="DELETE"/>

5.10.4 Strategy

This function is used to group members and tell MWAN how to distribute the traffic that uses this strategy in the "rule". Members with a lower metric will be used first, members with the same metric will load balance traffic, and members with a higher proportion will be allocated more traffic.

Click the "Strategy" tab to configure different policy rules based on the "Members" set in the previous step. There are 9 preset policies by default in the system, which are described as follows:



Name	Members assigned	Last resort	EDIT	DELETE		
wan_only	wan_m1_w1	unreachable (reject)				
wwan_only	wwan_m1_w1	unreachable (reject)				
3gwan_only	3gwan1_m1_w1	unreachable (reject)				
balanced	wan_m1_w1 wwan_m1_w1 3gwan1_m1_w1	unreachable (reject)				
balanced_wan	wan_m1_w2 3gwan1_m1_w1	unreachable (reject)				
wan_primary	wan_m1_w1 3gwan1_m1_w1	unreachable (reject)				
wwan_primary	wwan_m1_w1 3gwan1_m1_w2	unreachable (reject)				
3gwan_primary	wan_m2_w1 3gwan1_m1_w1	unreachable (reject)				
wan_wwan_4g	wan_m1_w1 wan_m2_w1 3gwan1_m3_w1	unreachable (reject)				

5.10.4.1 wan_only

Refers to using only the wan wired network (ignoring whether the 3G/4G SIM card or wireless WiFi network is normal);

5.10.4.2 wwan_only

Refers to only using WiFi network (no matter whether the wan wired network, 3G/4G SIM card is normal or not, it is ignored);

5.10.4.3 3gwan_only

Refers to dial-up network using only 3G/4G SIM card (ignoring whether the wired wan network or wireless WiFi is normal);

5.10.4.4 balanced

Refers to the simultaneous use of wan wired network, wireless WiFi network and 3G/4G SIM card dial-up network; the default traffic ratio of the three is 1:1:1, which can be modified in detail;

5.10.4.5 balanced_wan

Refers to the simultaneous use of wan wired network and 3G/4G wireless SIM card dial-up network; the default traffic ratio between the two is wan:3gwan1=2:1, which can be modified in detail;

5.10.4.6 wan_primary

Refers to wan wired network priority, 3G/4G wireless SIM card dial-up network backup; when the wan cable is abnormal or faulty, the network automatically detects and switches to the 3G/4G wireless network, and after the wan network is restored, the network traffic is automatically detected and switched to wan cable .

5.10.4.7 wwan_primary

Refers to the wireless WiFi network priority, 3G/4G SIM card dial-up network backup; when the wireless WiFi is abnormal or faulty, the network automatically detects and switches to the 3G/4G network, and when the WiFi network is restored, the network traffic automatically detects and switches to the wireless WiFi.

5.10.4.8 3gwan_primary

Refers to 3G/4G wireless dial-up network priority, wan wired network backup; when the 3G/4G dial-up network is abnormal or faulty, the network will automatically detect and switch to the wan wired network, and when the 3G/4G dial-up network is restored, the network traffic will automatically detect and switch again go back.

5.10.4.9 wan_wwan_4G

Refers to the wan wired network first, wireless WiFi backup, 3G/4G dial-up second; when the wan wired network is abnormal or faulty, the network automatically detects and switches to the wireless WiFi network, and when the wireless WiFi network is also abnormal or faulty, the network automatically detects and switches to 3G/4G dial-up network. At the same time, when the wireless WiFi network is restored, the network traffic is automatically detected and switched back, and when the wan wired network is also restored, the network traffic is automatically detected and switched back.

5.10.5 Rule

Click the "Rule" tab, the system will take effect according to the "policies" set in the previous step. The system default rule default_rule is balanced, that is, the wired WAN network and the 3G/4 wireless dial-up network can access traffic at the same time. Set other default_rule rules in the actual situation (6 strategies preset by the system can be selected. After selection, the 2 parameter allocation strategies shown below need to be modified to the selected strategy at the same time). as follows:

5.11 Intranet penetration (optional)

The peanut shell software is embedded in the router device, which is mainly used for the peanut shell intranet penetration function, which is convenient for remotely accessing the equipment connected to the router through the account server registered on the peanut shell official website.


5.12 Network Monitoring

This function (enabled by default in subsequent versions) periodically detects

and judges the continuity of the device's own network by setting specific conditions (2 conditions), thereby performing specific actions (such as restarting, etc.). details as follows:

1) Restart after disconnection

This condition sets the device to periodically ping to detect the IP address of a specific network host (the default interval is 60s, and the period is 10min), and determines whether to restart the device by judging whether the network is on or off.



Note: For the scenario where the VPDN private network is used or the device's own network is not allowed to access the external network, you need to modify the ping host address to be a valid address, or disable the network monitoring function, otherwise the device will periodically restart abnormally.

2) Periodic restart

Set periodic/timed restart for the device (default is 10min).

Network Monitor

Configuration

Operating mode: **Periodic reboot**

RebootPeriod: **10m**

Default unit is seconds, you can use the suffix 'm' for minutes, 'h' for hours or 'd' for days

SAVE & APPLY **RESET**

Premium Wireless Router v2.2.210114

6. Virtual Private Network

This chapter mainly introduces several different virtual private network functions and simple configuration and use. The virtual private network function is generally used to build a remote local area network between the user's field device network and the server network or different device network with different data transmission methods (such as PPTP/L2TP) or encryption strength (such as IPsec/Openvpn), To facilitate better and faster remote access and control of remote devices.

Note: For scenarios that use virtual private network functions (such as PPTP/L2TP/IPSEC, etc.), please turn off the device load balancing function to avoid causing the virtual private network to fail.

6.1 GRE Client

The premise of the main use scenario of the GRE network is that different nodes with access attributes of the public network or VPDN private network can realize mutual access communication between the subnet devices under the different nodes through the establishment of virtual tunnels.

1) Select "Virtual Private Network" --- "GRE" --- "GRE Tunnel", click the "Edit" button to proceed GRE related configuration, including tunnel source address, tunnel

destination address, tunnel address, etc., are as follows:

The screenshot shows two pages of the ZLWL Industrial 4G Router web interface. The top page is titled 'GRE VPN' and shows a table with one entry: 'gre1' (Status: RX: 0 B (0 Pkts), TX: 0 B (0 Pkts.)). Below this is an 'ADD' button and action buttons for 'CONNECT', 'STOP', 'EDIT' (highlighted with a red box), and 'DELETE'. The bottom page is titled 'Interfaces - GRE1' and shows a 'General Setup' tab. It includes fields for 'Protocol' (set to 'GRE'), 'Remote IP' (192.168.10.23), 'Local IP' (192.168.10.45), and 'Tunnel IP' (11.11.11.13, highlighted with a red box). At the bottom are 'SAVE & APPLY' and 'RESET' buttons.

Among them, the description of each parameter is as follows:

[Tunnel destination address]: Fill in the public network IP address of the opposite router, this example is the LAN WAN port address 192.168.10.23;

[Tunnel source address]: Fill in the public network IP address of the local router, this example is the local LAN WAN port address 192.168.10.45;

[Tunnel Address]: Fill in the virtual tunnel IP address of the local router, here is 11.11.11.13 (the opposite tunnel address is 11.11.11.14) as an example;

2) Set up the "Autostart" service as follows:

The screenshot shows the 'Advanced Settings' tab for 'Interfaces - GRE1'. It includes a checkbox for 'Bring up on boot' (which is checked), a 'TTL' field (64), and an 'MTU' field (1500). At the bottom are 'SAVE & APPLY' and 'RESET' buttons.

3) Take the local router subnet (192.168.3.0/24 as an example) to add the static routing table of the peer router network segment (take 192.168.4.0/24 as an example), as follows:

4) Configure the corresponding parameters for GRE on the other router at the opposite end, as follows:

The screenshot shows the ZLWL Industrial 4G Router web interface. The left sidebar includes options for System Status, Basic Network (Switch, Hostnames), Advanced Network (Static Routes, Wired Network, Mobile Network, Wireless Network, Static address), VPN Configuration (PPTP, LZTP, IPsec, EoP, N2N VPN, OpenVPN), and System Management (Logout). The main content area has tabs for Overview, Routes, GRE (selected), and Static Routes. The GRE tab shows 'Interfaces - GRE1' with a note about bridging network interfaces. The Static Routes tab shows 'Routes' with a note about specifying interfaces and gateways. Both sections include configuration forms with fields like Status, Protocol, Remote IP, Local IP, Tunnel IP, and Metric. Red boxes highlight the 'Tunnel IP' field in the GRE configuration and the 'Target' and 'Metric' fields in the Static Routes table.

6.2 PPTP Client

The PPTP network is mainly used to connect different client router devices or PC computer clients to the VPN server through PPTP protocol dial-up configuration to achieve the following two main usage scenarios.

Scenario 1: The PC client can remotely access any subnet host in different router clients.


Scenario 2: Subnet hosts between client devices of different routers can communicate with each other at will.

The schematic diagram is as follows:


Specific operation: Select "Virtual Private Network" --- "PPTP" --- "PPTP Client",

click the "Edit" button to configure specific parameters, as follows:

- 1) Select "Basic Settings" to start configuring server parameters and client account, password and other information, as follows:



The screenshot shows the 'PPTP Client' configuration page. On the left, a sidebar lists 'System Status', 'Basic Network', 'Advanced Network', 'VPN Configuration' (with 'PPTP' selected), 'ORE', 'IPsec', 'EOR', 'N2N VPN', 'OpenVPN', 'System Management', and 'Logout'. The main area shows a table with one row for 'pptp1'. The 'Actions' column contains 'CONNECT', 'STOP', 'EDIT' (which is highlighted with a red arrow), and 'DELETE'. At the bottom right, it says 'Premium Wireless Router v2.3.210811'.




The screenshot shows the 'Interfaces - PPTP' configuration page. The 'General Setup' tab is selected. It includes fields for 'Bring up on boot' (checked), 'Status' (RX: 0 B (0 Pkts), TX: 0 B (0 Pkts)), 'Protocol' (set to PPTP), 'VPN Server' (60.205.217.221), 'PAP/CHAP username' (chilink), and 'PAP/CHAP password' (a masked field). At the bottom right are 'SAVE & APPLY' and 'RESET' buttons. The page footer says 'Premium Wireless Router v2.3.210811'.

[Startup]: After checking, the router will automatically start and connect to the PPTP service every time it restarts

[VPN server]: Fill in the IP address of the remote server, generally the public network IP address;

[PAP/CHAP username, password]: Fill in the client account and password assigned by the VPN server;

- 2) Select "Advanced Settings" to configure some specific advanced parameters, as follows:



[Use default gateway]: After checking, the router can automatically address the server terminal network;

[MPPE encryption]: Fill in the encryption type consistent with the VPN server, otherwise you may not be able to connect to the server;

[LCP response failure threshold]: LCP response times, the default is 5;

[LCP response interval]: LCP response interval, the default is 3s;

[Activity timeout]: Inactive connection control with the server, the default is 0, which means that continuous connection is supported;

[Manually assign address]: You can specify the VPN address; set the format 172.16.100.2 (client virtual IP): 172.16.100.1 (server gateway virtual IP);

[Additional parameters for PPP]: Customize PPP parameters, such as filling in the debugging command (debug) or specifying the client VPN IP address, etc. (If you need to specify the VPN address, the setting format: 172.16.100.2 (client virtual IP): 172.16.100.1 (server gateway virtual IP));

3) The PPTP client connects to the server successfully, as follows:



The screenshot shows the ZLWL Industrial 4G Router web interface. The left sidebar includes options like System Status, Basic Network, Advanced Network, VPN Configuration (GRE, PPTP, L2TP, IPSec, EOIP), System Management (System, Administration, Backup / Flash Firmware, Network Diagnostics, Device Reboot), and Logout. The main content area has tabs for Overview, Routes, PPTP (selected), and Network Diagnostics. The PPTP tab shows a table with a single row for 'pptp1' with columns for Network, Status, and Actions (CONNECT, STOP, EDIT, DELETE). The Network Diagnostics tab shows a ping utility with an input field containing '172.16.10.1', a dropdown for 'IPv4', and buttons for PING, TRACEROUTE, and NSLOOKUP. Below the ping input is a text area showing ping statistics for the target IP.

Network	Status	Actions
pptp1	Uptime: 0h 1m 56s RX: 1.80 KB (39 Pkts) TX: 3.17 KB (73 Pkts) Address: 172.16.14.209/32 Gateway: 172.16.10.1	CONNECT STOP EDIT DELETE

PING 172.16.10.1 (172.16.10.1): 56 data bytes
64 bytes from 172.16.10.1: seq=0 ttl=128 time=103.278 ms
64 bytes from 172.16.10.1: seq=1 ttl=128 time=136.452 ms
64 bytes from 172.16.10.1: seq=2 ttl=128 time=101.070 ms
64 bytes from 172.16.10.1: seq=3 ttl=128 time=101.730 ms
64 bytes from 172.16.10.1: seq=4 ttl=128 time=100.358 ms
--- 172.16.10.1 ping statistics ---
5 packets transmitted, 5 packets received, 0% packet loss
round-trip min/avg/max = 100.358/108.577/136.452 ms

6.3 L2TP Client


The L2TP network is also mainly used to connect different client router devices or PC computers to the VPN server through the L2TP protocol dial-up configuration to achieve the following two main usage scenarios.


Scenario 1: The PC client can remotely access any subnet host in different router clients.

Scenario 2: Subnet hosts between client devices of different routers can communicate with each other at will.

The specific configuration is as follows:

1) Select "Virtual Private Network" --- "L2TP" --- "L2TP Client", click the "Edit" button to perform "Basic Settings", and begin to configure server parameters and client account and password information, as follows:





[Protocol]: Default protocol type: L2TP;

[VPN server]: Fill in the IP address of the remote server, generally the public network IP address;

[PAP/CHAP username, password]: Fill in the client account and password assigned by the VPN server;

2) Select "Advanced Settings" to configure some specific advanced parameters, as follows:

[Startup]: After checking, the router will automatically start and connect to the L2TP service every time it restarts;

[Obtain IPv6 address]: The default is automatic, you can choose to disable or manually;

[Use default gateway]: After checking, the router can automatically address the server terminal network;

[Manually assign address]: You can specify the VPN address; set the format 172.16.100.2 (client address): 172.16.100.1 (VPN server gateway address);

[MPPE encryption]: Fill in the encryption type consistent with the VPN server, otherwise you may not be able to connect to the server;

[LCP response failure threshold]: LCP response times, the default is 5;


[LCP response interval]: LCP response interval, the default is 3s;

[Response timeout]: Inactive connection control with the server, the default is 0, which means continuous connection is supported;


[Additional parameters for PPP]: Customize PPP parameters, such as debug, etc.;

3) Select "Encryption Method" to set whether IPSec configuration is enabled (default

is none), and the L2TP key is as follows:



4) The L2TP client connects to the server successfully, as follows:



6.4 IPSec Client

The IPSec network is mainly used to connect different client router devices to the IPSec server through the IPSec protocol dial-up configuration so that the client router subnet devices and the server terminal network devices can communicate with each other at will.


The specific configuration is as follows:

6.4.1 IPSec security strategy

The IPSec security strategy is mainly to set the server-related parameters, and configure the IKE/ESP security proposal, encryption algorithm, national secret SM3 algorithm and other parameter settings of phases 1 and 2 of the entire IPSEC communication.

6.4.1.1 Basic Settings

Select "Virtual Private Network" --- "IPSec" --- "IPSec Security Policy" --- "Basic Settings" to configure specific parameters. Examples are as follows:



[Enable IPSec service]: Check whether to enable;

[Local Security Gateway]: Fill in the local 4G dial-up IP interface (3GWAN1), the example is the local interface WAN;

[Local Subnet Range]: Fill in the client's local subnet range;

[Local virtual address]: The default is assigned by the opposite end (you can also choose to customize);

[Local security firewall]: Device local client security firewall parameters, check whether to enable;

[Peer End Security Gateway]: Fill in the server-side gateway IP (usually the public network or domain name address);

[Range of terminal network]: Fill in the range of server terminal network;


[Peer-end security firewall]: Device server-side security firewall parameters;

[Debug log]: After opening, you can view the specific connection debug log;


6.4.1.1 Security proposal

Select "Virtual Private Network" --- "IPSec" --- "IPSec Security Policy" --- "Basic Settings" drop down to "Security Proposal" to configure specific parameters, as follows:


Phase 1 configuration: Mainly configure parameters such as working mode (aggressive mode/main mode), encapsulation mode (tunnel/transmission mode), pre-shared key, security proposal, IKE lifetime, and DPD peer detection.




Phase 2 configuration: Mainly configure the security proposal, PFS parameters, and ESP lifetime of this phase.



XAUTH (extended authentication) configuration: User name/password can be set.



Custom settings: If both ends of the server-side settings are based on FQIN name ID authentication, you can configure specific authentication parameters, such as leftid (client authentication ID name) and rightid (server authentication ID name).



6.4.2 IPSec Security Alliance

Here you can view the tunnel establishment status and data flow at both ends of the IPSec. After the tunnel is successfully established, the following is as follows:

6.5 EOIP Client

This function is similar to that used by the GRE VPN client, but the authentication parameter here is the tunnel ID (0-500), and the specific configuration refers to the use of GRE VPN. as follows:


6.6 N2N VPN Client


The N2N network is mainly used to connect different client router devices or PC computer clients to the N2N super node server through the N2N protocol dial-up configuration to achieve the following two main usage scenarios.

Scenario 1: The PC client can remotely access any subnet host in different router clients.

Scenario 2: Subnet hosts between client devices of different routers can communicate with each other at will.

The specific configuration is as follows:





The screenshot shows the router's configuration interface. The left sidebar has a 'VPN Configuration' section with 'N2N VPN' selected. The main panel shows a table for 'n2n vpn' with one row. The table columns are 'Network' (N2N), 'Status' (Uptime: 0h 1m 8s, MAC-Address: A6:85:D5:9D:82:29, RX: 205 B (14x), TX: 746 B (77x)), and 'Actions' (CONNECT, STOP, EDIT). The bottom right of the interface says 'Premium Wireless Router v2.2.210114'.

[Version]: Super node server optional protocol version V1 and V2;

[Super Node]: Fill in the IP address of the remote central server, generally the public network IP address;

[Port]: The service port of the super node server;

[Community]: N2N constitutes a point-to-point network identification name. Note: The names and passwords of the two client nodes must be exactly the same;

[Secret Key]: The verification password of the child node community network, the passwords of different nodes must be consistent;

[Address]: The virtual IP address in a peer-to-peer network, usually a private network;

[Routing and forwarding]: Used to automatically forward and access different sub-node routing networks;

6.7 OPEN VPN


The OPEN VPN network is mainly used to connect different client router devices to the OPEN server after dialing through a specified protocol, so as to realize the following two main usage scenarios.

Scenario 1: The PC client can remotely access any subnet host in different router clients.

Scenario 2: Subnet hosts between client devices of different routers can communicate with each other at will.

The specific configuration is as follows:

1) Select "Virtual Private Network" --- "OPEN VPN" to configure related parameters. The default interface examples are given as follows:



OpenVPN

Below is a list of configured OpenVPN instances and their current state

Name	Mode	Enabled	Port	Protocol	Started	Status	Start/Stop	EDIT
opv1	client_tun_ptp	no	1194	udp	no	Disconnect	START	EDIT

Premium Wireless Router v2.2.210114

OpenVPN

Configuration

enabled

verb 3
Set output verbosity

port 1194
TCP/UDP port # for both local and remote

tun_ipv6
Make tun device IPv6 capable

nobind
Do not bind to local address and port

comp_lzo yes
Use fast LZO compression

keepalive 5 60
Helper directive to simplify the expression of --ping and --ping-restart in server mode configurations

proto udp
Use protocol

client
Configure client mode

remote 192.168.10.99

2) Then click the "Add" button to add the openvpn client CA certificate, cert certificate, and key key certificate generated in advance on the server side one by one, and correctly configure the server IP address and port number, use protocol (default is udp), etc., and save the application The post-connection conditions are as follows:

M2M wireless terminal

Cellular Router

OpenVPN Configuration

<img alt="Screenshot of the ZLWL Industrial 4G Router OpenVPN configuration interface. The 'OpenVPN' tab is selected. Under 'Client mode', the 'remote' field

The screenshot displays three pages of the ZLWL Industrial 4G Router's web-based management interface:

- OpenVPN Configuration Page:** Shows fields for LZO compression, keepalive, protocol (set to udp), and client mode. It includes sections for certificate authority (ca), local certificate (cert), and local private key (key), all of which are highlighted with a red box.
- OpenVPN Status Page:** Lists a single configured instance: 'ovpn1' (Mode: client_tun_udp, Enabled: yes, Port: 1194, Protocol: udp). The 'Started' and 'Status' columns show 'yes (26165)' and '10.8.0.17' respectively. Buttons for 'Start/Stop' (STOP) and 'Edit' are present.
- Network Diagnostics Page:** Features a 'Network Utilities' section with a 'PING' button (highlighted with a red box) and a 'TRACEROUTE' and 'NSLOOKUP' button. Below the PING button, a red box highlights the output of a ping command to '10.8.0.1', showing statistics for 5 packets transmitted and a round-trip time of 2.030/2.440 ms.

7. System Management

This chapter mainly introduces some system Settings of the router, such as system language, time zone, NTP server Settings and configuration of several network access modes.

At the same time, you can modify some system default management, such as login user name, password, shell background login access, etc. Finally, you can

perform instant/timed restarts, firmware updates, configuration file backups, and more.


7.1 System

7.1.1 System property

In this section you can configure the system host name, time zone and language Settings, or change the WAN mode Settings, etc. You can also update the system local time by clicking "Synchronize Browser Time".

7.1.1.1 General Settings

As shown in the figure below, you can change the host name (M2M by default), time zone, language, etc.




7.1.1.2 Modification of WAN mode

The router supports three different "WAN modes", as described below:

7.1.1.2.1 3G/4G and Wired (default)


It means that the device supports both WAN port network access (cascaded to the LAN port of the upper router, and the network segment of the two routers cannot be the same) and 3G/4G mobile network.



7.1.1.2.2 only 3G/4G


It means that the router only supports the SIM card mobile network and no longer supports the WAN network access (even if the WAN is connected to the superior network, it does not work);

You can further switch the WAN port to LAN by checking "WAN to LAN", so that you can connect to two user devices at the same time.




7.1.1.2.3 Only Wired

It means that the router only supports wired WAN network access and no longer supports SIM card mobile network (it will not work even if the SIM card is inserted and the network is successfully connected).




7.1.2 Time synchronization

The router system supports the NTP network timing service, and the device has several default NTP servers. You can also customize to add or modify other NTP servers.




7.2 Administration

In this chapter, you can modify the system's Web login password (default admin), Web access port (default 80), background SSH access (default LAN access, port 402) and other management permissions (in order to use the device safely, it is suggested that customers should change the default parameters when using the device).




7.3 Backup/flush Firmware

In this chapter, you can perform the following operations on the device system, such as firmware upgrade, backup parameters, reset, etc.



7.3.1 Generate Archive


For this part, you can download some of the current configurations by clicking the 'Generate Archive' button of the router for backup so that you can use it for the next time.



7.3.2 Perform Reset

The router system supports two ways to reset. Refer to the following instructions.


Method 1: Log in to the device Web page, and click "Execute Reset" to restore the routing system to the factory Settings. Please perform this operation carefully.



Method 2: When the router is powered on, long press the black RST button for about 10 seconds and then release it (all the lights except the PWR power lamp are on and off to complete the reset).


7.3.3 Upload Archive

For this part, you can upload the backup configurations file by clicking the 'Upload Archive' button of the router so that you have no need to configure it again manually. It takes about 2-3 mins, so just be patient. You can handle it like below.



7.3.4 Flash Image

For this part, you can upgrade the router device by clicking 'Flash Image' button. The upgrade process takes 2-3mins. Do not power off the device during this time, otherwise the upgrade will be abnormal and the system cannot be logged in again.



Note: Select the "Keep settings" button, and the system will retain the user's original configuration parameters after upgrade. When upgrading firmware across versions, it is recommended not to check this option to prevent incompatible use of some system functions.

7.4 System diagnostics

This chapter mainly introduces and instructs users how to confirm whether the router network is unblocked by using 'ping' (to test whether the Internet is accessible) and 'traceroute' (to track and view the network routing table) tools.

In particular, if you can ping an external network address (such as www.yahoo.com) successfully, the network is reachable. Otherwise, it indicates that the current network is abnormal and cannot be connected to the Internet, which requires further investigation and processing.



The screenshot shows the Network Diagnostics section of a network management interface. On the left, a sidebar lists system status, basic and advanced network, VPN configuration, system management, and administration. The network diagnostics section is active, with sub-options for network utilities, ping, and traceroute. The ping section is currently selected, showing a ping to www.yahoo.com with 64 bytes and a round-trip time of 181.376 ms. The traceroute section shows the path to the destination. At the bottom, ping statistics are displayed: 5 packets transmitted, 0% packet loss, and a round-trip time of 180.923/181.372/181.995 ms.



The screenshot shows the Network Diagnostics section of a network management interface. On the left, a sidebar lists 'System Status', 'Basic Network', 'Advanced Network', 'VPN Configuration', 'System Management' (with 'System' and 'Administration' sub-options), 'Backup / Flash Firmware', 'Network Diagnostics' (which is selected and highlighted in blue), and 'Device Reboot'. The main area is titled 'Network Diagnostics' and contains a 'Network Utilities' section. It features a text input field with 'www.yaya.com', a dropdown menu set to 'IPv4' with a 'PING' button, another dropdown menu set to 'IPv4' with a 'TRACEROUTE' button, and a 'NSLOOKUP' button. Below these controls, a red-bordered box highlights the PING output: 'PING www.yaya.com (59.32.181.150): 56 data bytes' and '--- www.yaya.com ping statistics --- 5 packets transmitted, 0 packets received, 100% packet loss'.

7.5 Device Reboot

7.5.1 Reboot now

Here you can restart the router immediately by clicking the Execute button if you need to.

7.5.2 Reboot timer

With this feature, you can set a specific time to restart the router system by date, hour, or minute.



ZLWL Industrial 4G Router Manual

Device Reboot

Reboot right now or set a reboot timer

Reboot now

Reboot Timer

Enabled

Hour: 0

Minutes: 0

Local Time: Wed May 19 17:08:29 2021

Period: Sunday Monday Tuesday Wednesday Thursday Friday Saturday

8. Exit

Clicking the "Exit" button will automatically log you out of the current device's web page and return to the re-login state.

9. Overview of Router Open Ports

Port	Protocol	State	Service	Description
53	tcp	open	domain	DNS
80	tcp	open	http	Web Server
402	tcp	open	ssh	SSH for Dropbear
443	tcp	open	https	Web Server

Appendix: Network Abbreviations

The following abbreviations are only listed based on the current router system (the order is not limited), and hope to provide basic help for you to understand some network terms.

abbreviation	describe
Host network access related:	
M2M	Machine to Machine
IP	Internet Protocol
IPv4	Internet Protocol version 4
IPv6	Internet Protocol version 6
MAC	Media Access Control Address
TTL	Time To Live
MTU	Maximum Transmission Unit
DHCP	Dynamic Host Configuration Protocol
DNS	Domain Name System
ARP	Address Resolution Protocol
Device/SIM card identification:	
IMEI	International Mobile Equipment Identity
IMSI	International Mobile Subscriber Identity
ICCID	Integrated Circuit Card Identity
USIM	Universal Subscriber Identity Module
SIM	Subscriber Identity Module
APN	Access Point Name
Operator network standard:	
LTE	Long Term Evolution
TDD	Time Division Duplexing
TD-SCDMA	Time Division-Synchronous

	Code Division MultiPle Access	
GSM/GPRS/EDGE	Global System for Mobile Communications General packet radio service Enhanced Data Rate for GSM Evolution	
FDD	Frequency Division Duplexing	
CDMA2000/HDR	Code Division MultiPle Access 2000 High Data Rate	
CDMA	Code Division MultiPle Access	
WCDMA/HSDPA/ HSUPA/HSPA+	Wideband Code Division MultiPle Access High Speed Downlink Packet Access High Speed Uplink Packet Access Enhanced High-Speed Packet Access	
Common network domains:		
WAN	Wide Area Network	
LAN	Local Area Network	
VLAN	Virtual Local Area Network	
MGT	Management	
WLAN	Wireless Local Area Network	
WWAN	Wireless Wide Area Network	
3GWAN1	3G/4G Wide Area Network	
PPPoE	Point-to-Point Protocol Over Ethernet	
PPP	Point to Point Protocol	
Common network protocols:		
HTTP	Hyper Text Transfer Protocol	
HTTPS	Hyper Text Transfer Protocol	



	over SecureSocket Layer
TCP	Transmission Control Protocol
UDP	User Datagram Protocol
ICMP	Internet Control Message Protocol
PING	Packet Internet Groper
Wireless WiFi use and encryption:	
AP	Access Point
STA	Station
SSID	Service Set Identifier
ESSID	Extended Service Set Identifier
BSSID	Basic Service Set Identifier
WMM	Wi-Fi Multi Media
WEP	Wired Equivalent Privacy
WPA	Wi-Fi Protected Access
WPA-PSK	WPA-Preshared Key
WPA2-PSK	WPA2-Preshared Key
TKIP	Temporal Key Integrity Protocol
AES	Advanced Encryption Standard
Firewall related use:	
QoS	Quality of Service
DMZ	Demilitarized Zone
NAT	Network Address Translation
SNAT	Source Network Address Translation
DNAT	Destination Network Address Translation
UpNp	Universal Plug and Play
ACL	Access Control Lists
Positioning/timing service:	
GPS	Global Positioning System



LBS	Location Based Services
MCC	Mobile Country Code
MNC	Mobile Network Code
LAC	Location Area Code
CID	Cell ID
SID	System ID
NID	Network ID
BID	Base station ID
BD	BeiDou
NTP	Network Time Protocol
Virtual private network use:	
VPN	Virtual Private Network
VPDN	Virtual Private Dial Network
GRE	Generic Routing Encapsulation
PPTP	Point-to-Point Tunneling Protocol
L2TP	Layer 2 Tunneling Protocol
IPSec	Internet Protocol Security
EoIP	Ethernet over IP
N2N	Node to Node
LCP	Link Control Protocol
PAP	Password Authentication Protocol
CHAP	Challenge Handshake Authentication Protocol
MPPE	Microsoft Point-to-Point Encryption
Algorithm and verification protocol:	
MD5	Message-Digest Algorithm
DES	Data Encryption Standard
3DES	TriPle Data Encryption Algorithm



SHA	Secure Hash Algorithm
DH	Diffie-Hellman
SM3	/
IKE	Internet Key Exchange
DPD	Dead Peer Detection
PFS	Perfect Forward Secrecy
ESP	Encapsulating Security Payload
XAUTH	Extended Auth